

Quick start manual

CONQUEST F5



www.conquest.net

Description



1. SIM card port
2. Fn button (Custom button)
3. PTT walkie talkie button
4. Barcode scanner (optional)
5. Strong torch
6. Front camera
7. Type-C port
8. Walkie talkie antenna (optional)

9. Volume + button
10. Volume - button
11. Power button
12. Main camera
13. Flash LED
14. Night vision lights
15. IR night vision rear camera
16. Fingerprint scanner
17. NFC area
18. Magnetic charging contacts

Dual SIM Standby

Dual + Standby, this means that the phone supports dual SIM but in Standby mode. In simple words, when neither SIM is used, then both SIMs are active, but when a particular SIM is used, the other SIM becomes inactive.

1. Dual SIM cards cannot use voice services and data services at the same time.
2. In dual standby mode, if one person is using SIM 1 and another is calling through SIM 2, you will hear the message "Unreachable, try again later".
3. When one of the SIM cards uses data services, the data services of the other SIM card cannot be accessed

Safety instructions

READ THIS INFORMATION BEFORE USING YOUR MOBILE DEVICE.

1. General Safety

- Please use the screen protector that does not block the light sensor to avoid affecting its normal use.
- Please use the official original accessories to avoid damage to the phone.
- Do not keep the magnetic stripe card with the mobile phone together for a long time, otherwise the magnetic stripe will out of action.
- Do not expose your phone to strong sunlight to avoid damage due to overheat.
- Do not connect with other Unauthorized equipment.
- Do not disassemble the phone.
- It is forbidden to put the mobile phone under high temperature or throw it into fire to avoid explosion.

2. Traffic Safety

- Please do not use the phones and follow the relevant traffic laws when driving.
- Do not place the mobile phone above the car's airbag or inside the area covered by the airbag released.
- Please comply with the relevant regulations of the airline. Do not use your phone in the area or during the time when it is forbidden. Please turn off your phone if necessary.

3. Medical safety

- The radio waves of mobile phones may affect some medical devices, such as pacemakers, cochlear implants, hearing aids, etc. The mobile phone and these medical devices should be kept at least 20 cm away. Feel free to consult the restrictions on the use of mobile phones with manufacturer when exception occurs.


USE TIPS 1

Quick Install SIM Card/SD Card


(Dual SIM Card or One SIM One TF Card)

1. Take out the card SIM card slot directly.
2. Place the SIM card/TF card securely in the card tray.

Dual SIM Card




One SIM / One TF Card




TIPS FOR USE 2

Before entering the water

SIM card cover should be firmly closed



Keep the speaker completely dry



WARNING

1. Before into the water, all ports and connections must be checked according to the above operations.
2. The phone's waterproof performance will be affected after a destructive fall.
3. Take the device out of the water, the speaker and receiver need to be completely dry before using, otherwise, it will affect the experience.

THE BASICS OF TROUBLESHOOTING

Problems and Solutions

Abnormal microphone/ Speaker/Receiver behavior post drop in water

Shake the phone dry to make sure the water is out of membrane. Use the hair dryer to quickly dry the excess water to restore the volume to normal.

App Crashes/Freezes/Unable to recharge/Restart frequently

Quick restart often solves minor issues with phone. On the right side of the phone you will find a power button. Restart the phone using that button.

Magnetic charger/Dock charger not working

Check the charger and the contact position for any signs of dirt or oxidation. A quick wipe with cotton swab and alcohol should solve the issue.

Abnormal power consumption

First, you should try to dim the screen brightness and turn off the GPS, WiFi and Bluetooth if you are not using them. Additionally, you should check your Battery Usage in your phone Settings and see which apps are using more battery. You can close or disable the ones that are draining more battery if you usually do not need them.

Unable to register the SIM card

If after proper installation of SIM card the phone doesn't recognize the network try switching the flight mode on-and-off or try restarting the phone. If the issue still persists clean the chip with alcohol and cotton swap.

MicroSD card does not work

Your microSD probably has errors and your phone is not recognizing that card. Try to connect a card reader to your PC and format the microSO card at least two times. Restart your mobile phone and insert the SD card again.

Mobile network not registering internet access

Go to settings-Network&internet-Mobile network-Mobile data-switch it on. Or slide the screen to shortcut menu-click the signal icon on upper right corner of the mobile data network- switch it on.

Restore to factory setting

Please note factory reset will erase all the data from the phone, so make sure you take the backup of data before you do a factory reset. Open settings-System-Advanced-Reset options-Erase all data (factory reset).