

Bluetooth Sport Headphones 9S - AB0010

To charge the battery

Before using the bluetooth headset for the first time, the battery must be full.

1. The charger cable connected to the charging socket of the headset.
2. Insert the charger into the power switch.
3. The charging indicator light shows red, when fully charged the red light turns off.
4. Isolate the charger from the handset and the power socket.
5. Charging is complete.

Switching on/off

1. Power on: press and hold the start/end call button for about 3 seconds, until red and blue alternate.
2. To turn off: press and hold the start/end call button for about 6 seconds, until it closes.

To pair the headset with a Bluetooth phone

1. Open the headset, press and hold the function keys for about 5 seconds until the red and blue lights flash.
2. Set the phone to search for Bluetooth devices.
3. When the phone searches for the headset, search the list for the headset.
4. If the match is unsuccessful, repeat the operation, just match at the same time.
5. If the pairing is successful, the blue lights will flash, at this point in standby mode and ready to dial/accept the call.

To answer a call / To end a call

1. According to the answer key on the phone.
2. Press the start/end call button on the handset.

To reject a call / To make a call

1. According to the hang up button on the handset. 2.
2. When the telephone rings, continue to hold the headset on the start/end call button for approximately 1 second.
3. Use the telephone keypad to enter the number of the call and then press the answer/call button, the call is automatically transferred to the headset.

To redial the last number called

1. In standby mode, press the start/call end button on the headset for about 2 seconds to loosen.

To adjust the headset volume

1. According to the volume + key to increase the volume on your phone.
2. According to the volume on your phone - to decrease the volume.

Safety considerations

1. Use the headset while driving. Please observe the regulations of your country or region.
2. Do not remove or modify the headset for any reason, otherwise it may cause headset failure or burn. Please send the headset to an authorized service center for repair.
3. Do not use the equipment in too low or too high temperature (below 0 °C or above 45 °C).
4. Extreme temperatures will cause deformation of the equipment, reduce the load capacity of the equipment and shorten the life of the equipment.
5. Wetting the earphones may cause serious damage to the equipment. Please do not use the equipment in contact with wet hands. Water damage to the equipment will void the warranty.
6. Do not use the equipment during thunderstorms. Electrical storms may cause the equipment to malfunction and increase the risk of electric shock.