## User Manual

Before using the smart wristband, please first go through this use manual

## Wristband appearance



### Start to use

Long press: Startup and Power-off Click: Return to the main interface, screen on, screen off

#### Operation description

1. Make sure the wristband has enough power to start up for initial use, otherwise please fully charge it. The wristband will automatically start up after being fully

Align the charging port to the charging adaptor to adhere both magnetically, until the wristband screen displays the

charging icon (charging for 2-3 hours continuously with a 5V charging adaptor)

2. Start-up: Press and hold the power key for 3s to start up

the wristband when it is under power-off state. The wristband will automatically start up when charging. 3 Power-off When the wristhand is under power-on state. press and hold the power key, the screen will display the nower-off interface, select YES then the wristhand will automatically power off; or slide down the main interface. click the Settings icon and enter the Settings interface. click System Settings to enter the corresponding interface and click Power-off, then the wristband will automatically power off (you can also restart and reset the wristband through this interface).



#### All-touch mode

The wristband is available for all-touch operations: The clock interface can be shifted upwards, downwards, leftwards and rightwards, and the subpage supports

# right-slide return.

Download and pairing 1. Search F Fit at a popular application store, and download the F Fit App, or scan the following OR code to download it. (Please attach the OR code diagram)

2. Open the APP, select the device that you intend to bind from the App's device list, and complete the pairing operation by following the tips. When pairing, please Make sure that the bluetooth names displayed on your phone and your wristband are identical. Equipment model After start-up, slide down to switch to the multi-function

interface, click the "Gear" icon to enter the "Settings" interface, then enter the "System", and click "About" to check the equipment model of the wristband, then find the corresponding equipment model in the APP terminal and click it to connect

In order to have better use experience. Please upgrade

your APP to the latest version when it is available.





O70C 59DO < ----- wristhand model V3 5<----- firmware version number ABCE<----- last four digits of MAC Bluetooth connection

icon is hollow

Google play

When the bluetooth is successfully connected a bar will be displayed in the bluetooth icon. Upon successfully connection, data will instantly synchronized to the App. and can be viewed at the App terminal, as shown in the lower right corner of the following figure

When the bluetooth is not connected, the bluetooth



## **Function introduction**

Theme interface display

Click Settings, and enter the themes to simply select different styles of clock display, or use more theme interfaces through the APP.



#### Normal mode display











Click the motion icon to activate the motion mode.

Motion mode

Support OR code download, settings, DND mode, Find My Phone, luminance adjustment



Find My Phone

Multi-function display

Click the "Find My Phone" icon, the phone term inal will vibrate or send sounds



Main interface slide-down

Menu list: Support more functional modes, as shown in the following figure



which supports nine sports, including running, brisk walking, mountaineering, cycling, football, basketball, badminton, table tennis, and swimming. In each sport mode, the sporting time, heart rate and Calorie consumption can be displayed on the interface. Click the motion icon to activate the motion mode, press and hold the side key to guit the motion mode.



## The wristband can't be identified when pairing.

Your phone must have activated bluetooth and is to be pairing in the "Supported Range", and please make sure the wristband is within 0.5m from your phone, and the bluetooth communication range shall not exceed 10 m from your phone after pairing!

Please check the power of your wristband, and contact us if the problem remains after charging the wristhand

2. Why there is occasional bluetooth connection failure? For certain phones, occasional bluetooth activation failure may occur: To establish bluetooth connection in case of such

failure, please simply restart your phone or reactivate the bluetooh

3. How to restore factory settings?

When the wristband is connected with your phone, open the APP, enter "My - My Equipment" and select

"Restore Factory Settings"!

4. How to undate the wristband's firmware?

"Firmware Update", then click "Upgrade"!

When the wristband is connected with your phone, open the APP, enter "My Equipment", and select

1. Avoid external force collision when wearing the

Precautions

2. Wipe the wristband with a clean and soft cloth to clean

3. Avoid exposing the wristband to chemicals and