

LCD Projector – K3




USER MANUAL

Please read this manual thoroughly before use this product and keep it for future referenc

PACKING LIST



Projector



Remote



User Manual




Power Cable

NOTICE


Recommended

1. Ideal for turning your living room into a movie theater, sharing fun videos at family gatherings and supporting your presentations at work with visual media projections.
2. Close the curtains and turn off the lights to enhance the visibility of the projected image.
3. Disconnect the device from power when not in use.
4. Disconnect immediately in case of spillage of any liquid near the projector to avoid short circuits.




Not recommended


1. Never place cloths or any cover over the projector, this prevents proper ventilation of the heat from the equipment and may cause damage.
2. Do not look into the lens of the projector when it is turned on, it can cause damage to the eyes due to the intensity of the light emitted by the projector.
3. Avoid sweeping or dusty activities near the equipment.
4. It can only be opened and repaired by authorized personnel.
5. Avoid having liquids near the projector, spills can cause irreparable damage.



FUNCTION OVERVIEW




1. Menú, 2. Power, 3. Return, 4. OK, 5. Power input, 6. Audio OUT,
7. USB 1, 8. USB 2, 9. IR receiver




1. Mute, 2. Power ON/OFF, 3. Volume DOWN, 4. OK button, 5. Menu, 6. Focus +,
7. Home, 8. Volume UP, 9. Direction key, 10. Back, 11. Focus -, 12. Input

QUICK START


1. Plug the power cord into a outlet




2. Press the power button to turn on the projector




3. Select the correct input source to project your device




4. Focus the ring to get the best image performance




5. Press the power button to turn off the projector




INPUT SOURCE

Press  on projector or remote control to enter the interface of **input source**


A. USB connection



PROJECTOR CONNECTION



PROJECTION DISTANCE & SIZE



SPECIFICATIONS

Display technology: LCD

Power supply: AC 100-240V 50-60Hz

Projection distance: 3.8 FT – 18 FT (1.16M – 5.5M)

Installation type: Front / Rear / Ceiling

Focus: Manual

Speaker: 3w / 4Ohm

Photo format supported: BMP / JPG / PNG / GIF / JPEG

Light source: LED

Unit dimensions: 6.45 x 6.3 x 6.77 inches

Unit net weight: 2.2 Lb (1Kg)

Resolution supported: 576i, 576p, 720i, 720p, 1080i, 1080p

Projection screen: 37" – 170"

Aspect ratio: 4:3 / 16:9 / Auto

Audio format supported: MP3 / PCM / FLAC / WMA

Video format supported: AVI / MP4 / MOV / MPEG1 / MPEG2 / H.264 / XVID

TROUBLESHOOTING GUIDE

1. Blurry Image

- * Adjust electronic focus/keystone.
- * Projector and screen/wall must be in effective distance.


2. Remote unresponsive

- * Make sure remote points at IR receiver directly.
- * Do not cover IR receiver.

3. Up Side Down Images

Enter "Menu" on projector or remote to flip the projection image.

Projection mode/Bluetooth speaker



Indicator status is as below at the power button:

Standby mode: red light

Working mode: blue light

Speak mode: blue light

After short pressing the power button, the projector is on

Enter speaker mode: In the working state, short press the power button to switch to speaker mode. After entering the speaker mode for 20 seconds, it will automatically enter the Bluetooth standby state

Exit speaker mode: In the speaker mode, short press the power button or any key on the remote control to exit speaker mode, and enter projection mode