

Bluetooth wireless headsets – P9 Model



Instructions

Power ON/OFF – Mode button:  / M

Play/Pause/Call button: 

1. Power on: Long press the "Power ON/OFF - Mode" button for about 2s, you will hear the voice: "bluetooth mode", the blue and red lights will blink alternately.
2. Off: Long press the "Power ON/OFF - Mode" button for about 3s, you will hear the voice: "Power OFF", the lights will turn off.
3. Pairing: Enter the search status after power on and find the product model, you will hear the voice "bluetooth mode", blue and red lights will flash alternately.
4. Successful pairing: you will hear the voice " Ding Dong" and the blue light will light up.
5. Disconnect: you will hear the voice " Dong " and the blue and red lights will flash alternately.
6. Turn on/off LED light: Three clicks or long press on the "Play/Pause/Call" button / LED light turns on or off as indicator.
7. Automatic pairing: Automatic pairing when power on, you will hear the voice: "Ding Dong" and the blue light will turn on.
8. Disconnect out of distance: (headphones enter into pairing status, blue and red lights flash alternately, headphones will automatically connect if move to working range in a few minutes, or automatically turn off after 5 minutes without connection; you will hear the voice: "Ding Dong" and the blue light will turn on.
9. Volume adjustment: Long press to buttons: "V+ / V-" ; Max/min volume: "DD".
10. Previous track: Short press to the button: "V-".
11. Next track: Short press on the button: "V+"
12. Play/pause: Short press on the "Play/Pause/Call" button .
13. Incoming call indication: You will hear a sound: Ling Ling.
14. Call answering machine: Short press on the "Play/Pause/Call" button.

15. Reject call: Long press on the "Play/Pause/Call" button.
 16. Redial the last number: Double-click on the "Play/Pause/Call" button.
 17. Hang up calls: Short press on the "Play/Pause/Call" button.
 18. Low battery indication: If the battery voltage is below 3.3 V., you will hear a voice prompting: "please charge".
 19. Low Power / Power Off: If the battery voltage is lower than 3.1V, you will hear a voice saying: "Power Off".
 20. Charging indicator: Red light on during charging.
 21. AUX IN: One plug on the headphones, another plug on the audio devices, you will hear the voice: "Power Off" and the indicator light will turn off.
 22. Charge complete: Once charging is complete, the red light will turn off.
- FM Mode: One click on the "Power ON/OFF - Mode" button, you will hear the voice: FM mode.
24. Auto station scan: Double click the "Play/Pause/Call" button / the blue light will flash.
 25. SD card model: Insert TF card to play music automatically, you will hear the voice: "SD card model".