

Kid's Tablet AT0011 - Q75X PRO



Instructions manual

1. In this system, parents can have control over five aspects: Application management, Internet filtering, time management, data statistics and multimedia management.


(1) Application management

This application allows parents to choose the right installed application for their children. See the following:



(2) Internet filter

This application has been designed to provide an Internet filter for children, so that it can be under parental control. See the following:



(3) Time Management

This application can restrict children's tablet usage time.

There are two sections:

1. Restrict children's daily usage time
2. Restrict children's weekly usage time.

As follows:



(4) Data statistics

In the statistics, parents can clearly recognise not only the specific usage, but also the usage habit of the children. See below:



(5) Multimedia management

In multimedia management, parents can add music, images and videos for children, so that children can open the associated programme in the children's panel and immediately enjoy these contents. In addition, all children can share those files. See the following:



2. Functions of the main panel

(1) The main parent panel

Allows control of all menus. See below:



(2) Login page for children

Login page for children

View as follows:



On this page, all applications selected by the parents will be displayed.

See below:



3. Features

(1) Automatic operation

The control system can operate automatically when the tablet is rebooted.



(2) Multiple account management

Parents can set up a disposable account for children, so that parents can conveniently supervise their children.



(3) Recommended APP for children

Parents can choose the apps selected here for children.

These apps will be updated regularly, so that children will receive the latest and most popular recommendations.



(4) Customise children's environment

Children can change the background image, application frame and login image.



(5) Exit


When parents have to deal with an emergency, they can exit the children's application to the main panel by pressing the exit button after entering the password.



4. Individual application CHILDREN'S MODE

(1) Children's camera

This children's camera replaces the original camera and has been redesigned for children, so that it will be easier and more suitable for them.



(2) Calculator for children

This application has been customised for children and is very colourful.



5. Main panel:

Children's panel

(1) Log in to children's account.



(2) Enter password (If the child's account has a password)



(3) Access children's homepage



(4-1) Access the children's home page after pressing the configuration button.



(4-2) Log in to the application, press the "Define application" button.



(4-3-1) The browser icon enters the browser page.

See the following:



(4-3-2) Enjoy the content




Parental Dashboard

(1) Click the login button on the child home page to access the parental control system.



(2-1) Go to the publisher's page and fill in the children's account details, such as name, date of birth, password or image.

The image shows an 'Account' creation form. At the top left is a back arrow icon and the title 'Account'. At the top right is a trash can icon. The form has two sections. The first section has a circular profile picture placeholder on the left. To its right are fields for 'Name' (containing 'Kid'), 'Birthday' (containing '2012-10-10'), 'Password' (containing 'Number'), and 'Gender' (with radio buttons for 'Boy' and 'Girl', where 'Boy' is selected). The second section is separated by a horizontal line and has a green plus icon in a circle on the left. It contains fields for 'Name', 'Birthday', 'Password' (containing 'None'), and 'Gender' (with radio buttons for 'Boy' and 'Girl', where 'Girl' is selected).

(2-2) Access the application from the parents' home page. So that you can define the applications for children.

The image shows an 'Applications' management page. At the top left is a back arrow icon and the title 'Applications'. Below the title is a table with three columns: 'App', 'Category', and 'Kid'. The table contains five rows of data, each with an app icon, a category name in a colored box, and a checkbox in the 'Kid' column. Each row also has a downward arrow icon on the far right.

App	Category	Kid
Kids Paint	Art	<input checked="" type="checkbox"/>
Spin Guess	Games	<input checked="" type="checkbox"/>
Rotating Gra...	Games	<input checked="" type="checkbox"/>
Typing Practi...	Games	<input checked="" type="checkbox"/>
Learning Ani...	Learning	<input checked="" type="checkbox"/>

(2-3) Parents can enter the Internet filter page. In this way, they can remove unwanted pages and add the most useful and suitable websites for their children.



(2-4) Enter the restricted time application to be able to determine and restrict children's account usage time.



(2-5) Access the data statistics application to view data in percentage and time of children's account usage.



(2-6) Enter the system configuration application, edit system information and settings. This information also applies to the children's account.

