



# SmartWatch U8

## Bluetooth



### STEPS TO CHANGE LANGUAGE:



Thank you for choosing our SmartWatch Bluetooth. You can synchronize this watch with your phone, it will offer you a complete set of tools to facilitate your work and leisure activities. The device has the following features: Bluetooth support for your phone, PUSH message technology (SMS, notes, QQ, etc., Android/iOS needed to install the Bluetooth notification APK), Bluetooth music player, calories, pedometer, sleep monitor, anti-theft / loss, remote trigger for the phone camera.

You can charge the device through a USB cable connected to a USB port, or to a wall charger.

Before you start using the device, you need to install the application on your Smartphone device to enjoy all the features available on your smartwatch.

There are three applications that allow synchronization between smartwatch and phone:

- Fundo Wear: Search in Google Play the app "Fundo Wear". Download and install it for Android.
- BTNotification: Search for "btnotification" in Play Store and download the second option that appears.
- "WooPartner": You can download the application directly from Play Store, searching for "BTNotification" (type in the search engine "btnotification"). Select the first application that appears.



For the correct use of the watch, always place it on the wrist with the power button on the right and the 3 touch buttons at the bottom of the display.



- Turn on / Main screen: Press to turn on the device. When the clock is in standby mode, press once to turn on the display.
- Confirm / Answer: to access the main menu and as a confirmation / access / answer button.
- Dial / Navigate: in the main screen (see image above) access to the dialing dial. Within the menus, to display the next menu, call function and music playback to adjust the volume.
- Back / Hang up: to back up menus and hang up calls.

In addition, by sliding / pressing with the finger on the touch screen, we find the following functions:

- Slide your finger on the screen: main menu
- Slide your finger from left to right/right to left: Navigate to the next/previous menu.
- Tap the screen: to enter the menu
- Slide your finger from the top to the bottom of the screen: Exit the menu.

**Connection method:** the clock starts together with the Bluetooth device to which it is connected (Smartphone).

**Double connection:** sharing the phone information to start the Bluetooth connection.

After a successful Bluetooth connection, the clock will automatically send a request to access information from the contact book and call log (for privacy reasons, some devices do not allow you to use this feature). Please check compatibility of the Smartphone, otherwise the clock will not be able to synchronize with the phone and will affect its normal operation in case of doing it wrongly.

If the distance between the device and the clock is more than 10 meters (without objects that obstruct communication, such as walls) will be automatically disconnected. Within 5 minutes after disconnection, when the devices are detected again, they will automatically connect to each other.

If the time is longer or they are not recognised, manual reconnection is necessary.

An audible warning will be produced if the connection between Smartphone and clock is correct.

## FEATURES:

- **Bluetooth:** searches for Bluetooth devices, connection, disconnection and other operations.
- **Dial clock interface:** click on the central button at the bottom of the screen to dial, this action can also be performed through the "Call log" menu.  
\*Do not block the loudspeaker or microphone during calls  
Information will be displayed when you receive sms.
- **Phone book:** synchronization of the phone book.
- **Synchronize phone call:** register of missed calls, incoming and outgoing, of the last 30.
- **Bluetooth music:** plays the music of the Smartphone via Bluetooth. In some devices it will be necessary to have installed a compatible player (phone's own player). Press the screen to access the controls. The + and - icons allow you to adjust the volume of the device. With the forward and backward arrows we move forward and backward between songs. In the center of the screen, you can control the playback or pause.
- **Remote camera trigger:** to control the phone camera via Bluetooth. To take pictures, it will be necessary that the phone is unlocked. (Some phones do not allow the use of this function.)
- **Pedometer:** Pedometer designed specifically for those concerned about health. Within the pedometer menu, you can indicate your own characteristics: sex (male – man / female - woman), height/cm (height in cm), weight/kg (weight in kg), step length/cm (length of step in cm), goal (goal of steps, an alarm sounds when you reach the number you have established). "Start" to start counting steps, and "Stop" to stop. In the central zone, it indicates the time and the number of steps. When we stop the count, we can save the data of the steps' count and time, we can see them again in "records", in the main screen of the pedometer.
- **Anti-loss:** when connected Bluetooth devices are separated from a certain distance, an alarm sounds on the clock.
- **Energy Saving Mode:** To use less battery.
- **Smartwatch adjustment:** tone, volume, language, display, battery charge, restore to factory settings.