

Smart Watch Instruction manual

- Thank you for purchasing this product. To make this product in the best use, please read this manual in detail, please keep the spare. The use of the picture only as a function of the diagram, and may be different from the kind, please take the kind of material. If the contents of the specification are not in conformity with the actual function, please refer to the information provided by the company for the subsequent release of the company. The printing error and the latest product will be updated in time. If there is a change, directly into the new version of the manual, no further notice. The company reserves the final interpretation.

1. Function introduction

Product modeling	Smart Watch
Machine reference size	46.75*40.8*11.2mm
Machine weight	50g
Pedometer	Sport meter steps, calories, mileage records
Sedentary reminder	The up movement, change unhealthy life style
Sleep monitoring	Objective scientific quantitative to record and analyze the status of your sleep
Looking for mobile phone function	The remind. Two-way searching
Bluetooth music player	Synchronous mobile phone music
MP3 ring	support
Phone book capacity	100
message	Synchronous mobile phone text messages
SMS capacity	50
The address book	Synchronous mobile address book
Phone calls reminding	support

1 / 4

Memory expansion	Biggest support 16 gt card, the best 8 gt card
Taking pictures	support
MP3 function	support
Recording function	support
USB function	The usb connector
Bluetooth version	3.0
The alarm clock	support
The calculator	support
The world of time	support
A stopwatch	support
Specifications and your battery capacity	380 mah large-capacity polymer
The charger specification	5 pin micro usb connector
Cable specifications	5 pin micro usb connector
Other features	Lift the wrist bright screen, screen calls mute, power-saving mode, etc

2. The instructions

Open the key: long press, switch machine; Short press, return function.

After startup, a standby clock interface, point the middle switch another kind of style, to swipe left into the main interface, up and down to the up and down or so after enter the main menu, after entering each function, there are options operation, some interface without options, after returning to the right and the left menu swiping is into the next level, if on screen or on the crash cases, remove the battery pack again to boot is good.

The machine factory default: the original password is 1122.

3. Bluetooth push service applications

A. "Bluetooth android mobile phone, first download the APK application notification" or "points move partner" software to smartphones, and install the APK, can realize the connection with watch. Two can only choose one, do not install two at the same time, download method:

Mobile phone via a browser can scan qr code on the main menu, watches directly into can only choose one after download,

- 1, notify the android bluetooth version (MTK official version)
- 2, dynamic partner android version (research and development of the company based on MTK platform version)

2 / 4

Or on the application platform search "bluetooth notice" or "points move partner" directly downloaded to mobile phones. After the download is complete, mobile phone Settings - auxiliary functions - bluetooth notification or partner to open, let mobile phone with bluetooth connectivity, when there is the bluetooth logo watch, said connection to complete.

B, to watch after apple mobile phone via bluetooth connection, when the bluetooth logo appears on the watch, said the connection is complete, the watch can be synchronized on the phone contact, phone records, the bluetooth music playing.

Warranty that

1. This product in normal use, if appear because of manufacturing, materials, design of causes of quality problems, since the date of purchase, one year free warranty.
2. The fault caused by the users personal reasons, don't provide free warranty, as follows:
 - 1). To tear open outfit, failure caused by modified watches.
 - 2). In the process of using immodesty drop caused by the fault.
 - 3). All human two-string fiddle bad or by a third party negligence, misuse (such as: the host into the water, the external force shatter, scratch damage of peripheral components, etc.), is beyond the scope of the warranty.
3. When asked to provide free warranty, please must provide a warranty card with the seal of purchase date and place.
4. A user maintenance products, please take the product to the company or the company dealerships.
5. All functions is given priority to with real products.

Purchase date:

IMEI code:

Buy store:

Customer signature:

3 / 4

The clerk signature:

The store stamp: