


## 1. Notes

1.1 The company reserves the right to modify the contents of this manual without any further notification. It is normal that some functions may vary in certain version of software.

- 1.2 Please charge this product for more than 2 hours before using it.
- 1.3 Safe password of this product

The safe password of this product can prevent other people from using your product without authorization. The original password of this product is 1122. In order to ensure the security of your personal information, please modify the original password and firmly remember it.

1.4 You should open the battery cover for fixing SIM card(corresponding screws and screw drivers are included in the package)



### Loading method of SIM card:

1. Unscrew and open rear cover.
2. Move away battery gently (Caution not break the line)
3. Push and open the SIM card by following the direction of OPEN.
4. Load SIM card and push gently by following the direction of LOCK and lock.
5. Load battery and cover the rear cover and tighten screw.

"security and privacy" of the cellphone settings, then it can be installed normally.

2. To ensure App's operation at background, when you use background cleanser or shut off the background application software, please do not close this Bluetooth notice service. If it close, the synchronized transmission between the watch and cellphone will be affected.

3. Bluetooth should be on.

4. Open: Phone settings-Auxiliary functions-Service, and choose "Turn on".

## 3.3 Connection and synchronized functions of blue tooth

### 3.3.1 Connect the watch from cellphone

Enter phone settings-Bluetooth settings-open bluetooth. Click to search equipment and choose pairing when the smart cellphone watch device is found, on the watch also choose "Yes", pairing succeed. (Note: it should be confirmed that the device can be searched from smart watch) When there is Directory request, please click "OK" and it's suggested to choose "Don't Remind Next Time" at the same time, to facilitate the synchronization of directory when it is connected next time without reminding you again.

Note: Open the synchronized software in the cellphone's auxiliary function with synchronized software installed. At the phone it will show the bluetooth notification opened within 2-5 seconds after connection. At the same time when watch prompts that it synchronizes with the date and time of remote equipment. Click "Yes", then the time of cell phone is synchronized automatically, and the function of synchronization is enabled. When your cell phone received new message and prompts, they will be synchronized to smart watch timely.

### 3.3.2 Connect cellphone from the smart watch

Choose "Menu-Bluetooth-activate bluetooth" on the smart watch, and then click "search bluetooth device" from "my setting", to find your smart cellphone (e.g. Samsung S800)--choose "Pairing", the following procedures are the ditto of that in 3.3.1:

### 3.4.21 Multimedia

Video player : play video

Record sound : the sound saved in watch, it is suggested to add TF card to save storage.

### 3.4.22 Album

scan the pictures saved in watch

### 3.4.23 Action

The screen turn bright when hang up your arm, you can set turn on or off.

### 3.4.24 Tool

Alarm: Add alarm and set ring.

Calculator: Can operate simple calculation of addition, subtraction, multiplication and division.

## 4. Precautions for use

4.1. Please charge fully before use. The charging time needs 1-2 hours. Please check if the connecting place is right while using magnetic charging cable.

4.2. For the charge cable, the quality charge cable of Android phone should be used, or standard charge accessory.


4.3. Bluetooth disconnects when it exceeds the distance during the process of use. After the anti-lost is enable, the search function can not be used without connection again.

4.4. During the process of use, the bluetooth will disconnect occasionally. Please connect again. It should be connected once manually when it is being disconnected exceeds five minutes. When it is connected, please choose to agree the synchronization of telephone, or the phone contacts will not be displayed, neither the related remote control function.

4.5 Music: It can display the names of songs or partial cell phones do not display the names of songs according to the different Android cell phones. It is normal. It is caused due to different cell phones.

## 2. Product Overview

### 2.1. Basic introduction



### 2.2 Operation of this product

1. Enter menu by sliding right and left at stand by interface, slide right to enter next menu, slide left back to last menu. You have to slide long enough over half the display screen, in case that recognized as a click by mistake.

2. Besides power on and off, when press the power button can turn back to the stand by display; the back button function as turning back to the last step.

### Comparison table of function icon :



Note: The cellphone Bluetooth should be open and is allowed to be searched by surrounded Bluetooth devices.

## 3.4 Description of function menu

3.4.1 Dial : Click dial key to enter the dialing interface, it will prompt local dial and bluetooth dial after inputting number. If it's not connected with phone, the bluetooth dial will display dark color and the function is unavailable.

### Phone answering:

When received phone call, the phone has ring remind, it display number and named person caller (ID business), you can choose the icon weather to answer the phone or hang up.

### 3.4.2 SMS ( when bluetooth is connected )

1. Write message : Edit SMS and send to local contacts and bluetooth contacts
2. Inbox : Read and reply to local and bluetooth SMS, call the sender, delete and check details.
3. Drafts: Save the unsent contents as draft.
4. Outbox : you can check the message already be sent.

Contact : This function as searching, adding and deleting contacts. Including local contacts and bluetooth contacts (if cellphone is connected. Bluetooth contacts can be synchronized the cellphone to dial and answer the phone.)

1. Create and edit contacts.
2. Click and touch the icon of creating contact at the interface of contacts list.
3. Click and touch certain contact or edit/delete contact through selection of menu key for the saved contact.
4. The name and telephone information of contact can be saved.

## 5. Common troubleshooting

If any problem happen when use the smart watch, please refer to the what below to solve it, if problem still exists, please contact distributor or specific maintenance personnel.

- 5.1. Watch can not be powered on. Press power button for too short, please press long enough exceed 3 seconds. Battery power is too low, please charge.
- 5.2. Watch power off automatically. Battery power is too low, please charge.
- 5.3 Working time is too short. Not charge full, please charge enough time (at least 2 hours.) The signal at your place is poor when using SIM card, cause too much electric current.
- 5.4 Can not charge watch normally. Please check if battery use full, the battery's performance reduced after it use for years. Please check if the charge cable work normally, change a new one if not. Please check if the usb cable connect well, if not try once again.
- 5.5 No caller name displayed when receive calling. When bluetooth connected, you don't choose to upload the contacts; or you can't mark uploading contacts always; When it is connected again after breaking, you don't synchronize the contacts, please pair and connect again.
- 5.6 Sound quality of phone call communication is poor. The distance between smart watch and phone is too long, please be closer; The bluetooth signal is poor. The phone call signal at your place is bad, change the position of calling and answering telephone.

## 2.3. Setting of the watch dial

### Watch dial effect pictures and setting methods:




Method 1 : Power on, press long the screen at the idle screen, then you could enter the interface of clock type choosing interface, so you can change the display effects by sliding left and right according to your own needs.

### 2.4 Theme setting

Enter main menu-theme, enter the interface to select effect theme according to your own likes.

### 2.5 Wireless charge stand

The watch support wireless charge, with wireless charge stand. If you need this accessory, please contact us to buy additionally.



### 3.4.4 Call center

#### Call history

1. Check the latest phone call record.
2. Dial directly, edit the contacts in call records, save number in contacts.
3. Turn to SMS interface directly to edit message.

#### Call settings

1. Call waiting; you can set on/off.
2. Call diverting; set call diverting according to your different needs.
3. Call barring; set call barring according to your different needs.

### 3.4.5 Bluetooth dialer

You can search the bluetooth device nearby, pair and connect.

### 3.4.6 Remote notification

Display the synchronous information from phone, eg : SMS, time, Twitter, Facebook, ect.

### 3.4.7 Remote photo-taking:

Control the phone camera from watch, the pictures are saved in phone.

### 3.4.8 Heart rate monitoring

Click to monitor heart rate at real time

### 3.4.9 Voice recognition

Support Android and Iphone, but Baidu voice assistant (apk) need to be installed, it's normal that the function can not work in some phone because the bluetooth may not compatible.

### 3.4.10 Anti-lost

After connecting by bluetooth, if the distance between watch and phone is beyond the bluetooth search range, it will prompt from watch; you can choose ring or vibration as remind type.

### 3.4.11 Pedometer

In the pedometer menu, click start, it can record steps, consumed calorie, distance, ect.

## 3. Quick use of this product

### 3.1 Download synchronized software ( only support Android )

Method 1. Enter the menu and find QR code, scan it with the software that has the scanning function in your phone, then can enter the download interface of synchronized software.

Method 2. Input the following website to download.

<http://pan.baidu.com/s/1o670LT4>

you can download corresponding software according to your need, then install the app normally following the prompts of phone.

### Note :

1. This program is only used for synchronization between watch and cellphone, and no cellphone network traffic will be consumed.
2. Although the traffic is consumed during the process of downloading program, it is recommended that download should be done in wifi mode.
3. If you have downloaded relevant software from other channels, please check the software version, and use the latest version of synchronized software to ensure the normal use of its functions. Please update the synchronized software, when new version come out.

### 3.2 Installation and use of sync software

Installation of application software :

When downloading is finished, it enter installation mode automatically and remind you whether to install. If there is no direction for installation, you can find the downloaded APP document in the smart cellphone to install, installation procedure will carry out normally.

### Notes:

1. If installation fails in some Android phone, please close "unknown sources" in

### 3.4.12 Sleep monitoring

Click to power and your sleeping time will be recorded to show your quality of sleep and check the history in the options.

### 3.4.13 Sedentary remind

The remind time can be set as 10 mins, 30mins and 60 mins.

### 3.4.14 Setting

1. Time and date : you can set time and date in your watch, choose the summer season or not according to your need.
2. Language : you can change the language as your need.
3. LCD backlight : adjust the brightness by sliding.
4. Bluetooth : you can choose activate bluetooth or not, set the watch if can be searched, change the bluetooth device name.
5. Restore settings : reset the watch, password : 1122

### 3.4.15 Theme mode

According to the theme you choose, the menu background color is different.

### 3.4.16 QR code:

Scan QR code from your Android phone, install bluetooth notification (apk), connect by bluetooth then synchronize with phone.

### 3.4.17 Music

After connecting with phone by bluetooth, it can play the music in your phone; if have TF card in watch, it can also play music.

### 3.4.18 Camera

The photos are saved in watch, it is suggested to add TF card to save the storage.

### 3.4.19 Documents

You can check the file contents saved in watch and TF card.

### 3.4.20 Profiles

You can select standard mode, silent mode, meeting mode and outdoor mode.

Warranty Card			
Customer Information			
Model	Company	Signature and seal	
Customer name	Contact telephone number		
Sales telephone number	Date of purchase		
Product IMEI code			
Customer address			
Sales address			
Abstract			
Date	Fault	Overhaul	Remarks