Smart watch Instruction

Thank you for choosing our product!

To have a comprehensive understanding of the use of this device, and know useful features and simple operation method, please read this manual first.

The functions on the user manual may be little different with physical, please make the final products as the standard.

The typing errors in this manual and discrepancies will be timely updated with the latest products. If we have updates, this manual will be subject to change without notice. Our company reserves the right of final interpretation.

1. Bluetooth Push Service Application Operation

Android user:

please download the application "APK" or "Fundo Companion" first. Only after installation of the" APK", your phone would connect with your watch. Notice: the application "APK" and "Fundo Companion", you only select one, and you can't choose both.

The method of download

Through the browser, phone can download the App from watch through scanning the QR code. Choose only one from "Fundo APP Android" or "Bluetooth Notice", don' t install both.

- 1. Mediatek Smart Device
- 2 Fundo APP

You can search them in application platform also, and then download them. Please turn on the "Fundo APP Android" or "Bluetooth Notice"; Phone setting - "Accessibility Feature" - "Fundo APP Android" or "Bluetooth Notice", Turn on Bluetooth of your phone. When the sign of Bluetooth appears, it means connection is done.

iPhone user

Connect the watch with iPhone by Bluetooth, the watch will auto sync phonebook, call logs, massagers and music.

2. Watch instructions

Power button: Long press for turning on or off; button above press for going back to the standby interface. After turning on, long press the screen in the middle to switch another style. Tap up and down into the main interface. Tap up and down to the main menu. After entering each function, tap right to return. Tap left to move into the next level. If the watch crash, just long press the power button, that is good.

Changing: Because of the product configuration is magnetic suction charging line, as shown, aim the cable on the back of the watch contact, will automatically absorb, recharged.

Reset device password: 1122. if the watch crashed, reset it, everything will be recovery.



3. Function

Home: Main Menu has Smart Circle Apps & 4 Apps Styles

Main Functions Instructions:

- . Bluetooth Setting: It shows below menu to choose
- 1) Power ~ Turn on or Turn off
- 2) Visibility ~ Turn On or OFF.
- 1) Silent
- 2) vibration
- 3) Ringtone 1
- 4) Ringtone 2
- 5) Ringtone 3
- Sleep Monitor: Monitor your sleep quality.
- . Languages : set your watch Language.
- · Pedometer: Calculate distance timing, and kilometer.
- 1) Steps ~ Start steps calculation, distance(km), Calorie(kcal).
- 3) Step distance set (cm) ~ Base on personal height.
- 4) Weight Set (kg) ~ Base on personal weight,
- 5) History clear Clean all history data,
- Stopwatch : Countdown
- · Alarm : Max 5 alarms setup.
- · Heartrate Monitor: Be closed the wrist watch, can be measured in real time, as a

general rule, be 60-90 times/min

- . Thermometer: Be closed the wrist watch, measure body temperature in real time,
- UV : Put watch in the sunshine, can measure the intensity of UV light
- Massager; Through the vibration massage, alleviate your fatigue.

- 3) My Device ~ Search other devices and pair
- 4) My Device Name ~ Check the device Name or Rename.
- Phoebook: Local contacts & Bluetooth contacts, 500 contacts max for Local, All
 the contacts from Sync
- Dial :Local call & Bluetooth call, make phone call by Sim card or Bluetooth devices.
- · Call logs: It shows below menu after open.
- 1) Missing call ~ It shows missing calls, and call back.
- 2) Dialed ~ It shows called contacts, and call again,
- 3) Received ~ It shows received calls and call back.
- 4) All ~ All the call logs of phone & watch.
- QR Code; Scan the QR Code by any Scan tools, download the App in smart phone.
- Notifications: Receive phone apps notifications, it works when connected with Fendo APP
- Music Player: Local Music & Bluetooth music, local music can save in the watch memory, Bluetooth music can play smart phone music, all sounds from watch speaker.
- Remote shot. Android phone under unlock., sync phone camera take photos, save in phone memory.
- · Setting: Set up device all the functions.
- Search my Device: After activity, if the watch from phone faraway, both of them will warning.
- · Ringtone : Change different Ringtone, below choice.

year (since the day of purchase), we will offer free warranty. Premise is using normally and correctly.

- About the fault caused by the users personal reasons, we don't offer free warranty, as follows:
- 1). Disassemble or refit the product.
- 2). Caused by immodesty drop
- 3). All artificial damage or misuse (such as; make water into the host, the external force shatter, scratch damage of peripheral components, etc.), all these are beyond the scope of the warranty.
- 3. When ask for free warranty, you must provide a warranty card with the seal of purchase place and purchase date.
- If you met problems during use, please contact the shop customer service which you bought from.
- 5. Please make the final products as the standard.

Date of purchase:

IMEI code:

Buy store:

Customer signature

Clerk Signature:

Shop stamp: