

User manual for Bluetooth smart watch

- X Thank you for choosing our watch devices. You can completely understand the method of using it and realize its perfect function and concise operating methods by reading
- ※ Bluetooth version: BT4.0
- * Remark: Please connect the watch to mobile phone via Bluetooth successfully before using the watch.
- * The requirement about mobilephone operation system version

Android users: support the original operating system Version 4.44 or higher. (Settings-About Device, view the android version) Iphoneusers: supportversion 8.0 orhigher. (Please update your phone if it's not 8.0 version. you can find it in mobile phone etting-general-about)

How to download Fundo

How to get the Fundo APK for Iphone and Android users

1. For both Android and Iphone users: Scan the QR code on watch or user manual through

smart phone or Qqsweeping function to download and install on phone



※ Tips: WeChat only supports QR code scanner to read, doesn't make sure your phone have enough memory space and the operating system version is

2. Download the Fundo Wear from Google play store and APP store:







※ Fundo Wear register and log-in, bluetooth connection

1. After installing the Fundo Wear. enterinto mobile phone setting -bluetooth-open(Andriod should be visiable, Iphone should open location services, settingprivacy-location services-on

If there is nonrompt message during bluetooth

register successfully, or the

releventdatas can't be sync

2. Open Fundo Wear afer

completing thephone settings,

login screen will popup, you

by QQ/WeChat account.

3. Enter into the Fundo interface,

click the"+"at the right bottom

appear, click it tosearch. After

message will come out, choose

successful, Android users can

corner, bluetooth icon will

seraching, click the watch

name to connect, a pairing

"Pair". Fundo connection is

use all the functions on

connecting with the Fundo

successfully, enter into phone

settings-bluetooth-on, search

the watch name and connect.

pairing message will come out,

For Iphone Users, when Fundo

occurs flash back, please make

sure your location services is on

Please make sure your Fundo is

choose "pair", then you can

use all thefunctions on watch.

4. For iphone users, after

SmartWatch

%Tips

can register by email, or login

Clock: You can set different types of clock and set the time and date in watch after closing synchronization functions.

Sound: You can customize the notification tone, ringtones and notification tones in watch

Volume: You can adjust the volume of multimedia. ringtones and notification tone in watch.

Display: You can customize the wallpaper, screen brightness and backlight turn-off time in watch.

Movement: When this function is set to be open and saved, ringing from incoming calling and alarm clock can be converted to mute automatically by turning over the watch. Under the turn off status, turn over the watch and the screen will be bright automatically.

Multilingual environment: personality setting the synchronize, language name display automatically

connecting, maybe because connectthe wrong device. You can open thesettings-about on watch, and check ifthe bluetooth device address is thesame as your connected device. If not. please choose the right one.

*** Instruction to watch** operation

Side button: long press for switchON/OF, short press for return back to menu

TP gesture(secondary or third menu): Slip from left to right means turn back from right to left means confirm: Switch the interface by sliding leftand right.

Introduction to Menu **Functions**

Click on the menu and view all contact list (about 500 contacts) .search for anycontact quickly and call him/her.

Dial via the watch after connecting withyour phone

Call record

Enter into the menu and can synchronizeall call records on your phone, click onthe record and can call them again

Please install the Fundo Wear on yourphone before using this

functionClick on the menu and view all inboxmessages, reply to the sender in SMStemplates and make phone call (view the SMS menu in IPHONE is not allowed)

Notification

You can synchronize all instant messageson the phone.

Findphone

Press this function, phone will have an alarm and vibration of the bluetooth signalis unstable or distance between watchand phone is longer than 10 meters, watch will have an alarm .

alarm

You can have 5 custom alarmclocksPrompt setting: Vibration and ring\Vibration\RingReturn back to the clock menu, set the switch as ON station

calendar

Enter the calendar interface and slide upand down as well as left and right to exit

Music

Click to enter the menu and can synchronize all the songs in the pairedphone, click on any one song to play, adjust volume, pause, skip the song and so on. Turn off the music when recording, connect again if need to play the music

phone (unlock the phone at first), you can preview the image, click on the shoot, pictures can be stored in the paired devices (but every phone has adifferent store path, pictures may bestored in albums or memory card, viewing pictures at once is not allowed through some kind of phone you may view pictures a few minutes later or by restarting the phone. This phenomenon has nothing to do with the watch, it depends on different mobile phone models)The function is not allowed in IPHONE.

Enter into the menu to open

the camera on the paired

Remote camera

Bluetooth connection

Open this function, you can seethefollowing menuBluetooth sycn, search for the other bluetooth device and send a pairing connector Bluetooth setting: Bluetooth ON/OFFsetting and amend the device name

File management

Enter in this function to view thephotos, video, audio files in the watch

Pedometer

normal arm swing will start step counting during walking, the first ten steps

will be estimated as one step. whichdetects whether you are walking or notYou can set the target step number in daily exercise (you will be reminded afterreaching the target) Personal informationsettings (height, weight)Historic record: a historical record about the step number of daily exercise will be generated in the morning.

Sleep monitoring

Enter the sleep monitoring menu, click"Start"and then wear it in hand and go tobed, user sleep quality can be monitored according to vibration amplitude of thewatch and duration of sleep, and a historical record about sleep duration and quality will be generated automatically in the morning every day, up to twenty historical records can be generated.

Display style Different display style for option

Reminder for long-time sitting Click into the reminder menu for long-time sitting, you can set your own timeperiod

(in half-hour increment), and the watch will ring and vibrate to remind youexercise after long-time sitting.

Heart rate & ECG

Please make sure to wear the watch suitably before

measuring heart rate and the watch should be glued to the skin closely. Click Start to measure the heart rate.(please don't move your arm)A historical record will be generated for each data measurement automatically, up to 20 historical records can be generated.

Record

You can record and play local audio files.

Siri

This function is only for Iphone. By the siri, you can give the commands through watch to use the related functions on Iphone.

QR Code

Scan the QR Code by QQ sweeping or sweeping on Android phone, press download and install

Stopwatch Calculator

For calculation

Settings

Bluetooth settings (you can activate and turn off Bluetooth, if there is any paired device, you can disconnect the Bluetooth to close; you can turn off the device, if there is any paired device, it will go into automatic shutdown.)


APP: Uninstall the installed app in watch

Restore settings: restore the watch to the factory setting status.

The battery can't be removed. Due to the loss of product itself in idle for more than one month, device will be unable to turn on because of no power.Improper operation may cause the product crash, reset the product by long pressing the

The schematic of shorten the watchband

Change the length by yourself: with the help of the tool (you can find it in the giftbox). take out No.2 or No.3 surplus watch chain and keep No.1 and No.4(like the picture shows) (Attention: this action may scratched the watchband, we don't recommend)



Please contact the watch repair stores to change the band length