

Wireless Speaker Specification



- **charge** External 5V charge for this machine ,charging LED light
- **ON/OFF** Switch to the "ON" position to boot, the "OFF" position for shutdown.

● The Key Operation

- 1 **M** Short press: Wireless / autodyne /USB/TF/RADIO/AUX switching.
- 2, "**⏮/V-**" Long press: for the volume reduction.
Short press radio model for the last station, MP3 mode is a song.
The self timer mode short press "**⏮/V-**" button for the self timer function
, (only for Apple mobile phone system)
- 3 **⏭/V+** Long press: the volume and.
Short press: Radio Model for the next stage, the MP3 mode for the next song.
The self timer mode short press "**⏭/V+**" button for the self timer function
(only for Android phones)
- 4, "**⏮⏭**"
MP3/ radio / Wireless state short press play / pause . Radio status long
press for the auto channel search.
Incoming short press the "**⏮⏭**" key to answer the phone
Long press "**⏮⏭**" to hang up the call, short press the "**⏮⏭**" key "to switch
between phone calls / Wireless speakers answer"
Wireless status long press the "**⏮⏭**" key to dial back the last telephone

● The Self Timer Funtion

- click "M", from the Wireless mode to the self timer mode
- open the Wireless mobile phone, search for "shutter", click on the link
- open mobile phone camera interface, press "**⏮/V-**" or "**⏭/V+**" button
- to take pictures

Attached: Android system requires 4.2.2 IOS requires version 6.0nd above, the other version does not support. Mobile phone with independent pictures button generally do not support.

Bluetooth connection to other bluetooth operation methods

- I. Open two bluetooth speakers at the same time
- II. Long press "MODE" key(Heard "tick" is ok)
- III. Wait for the two bluetooth speakers to interconnect(Two speakers also appear the sound at the same time,express connect success)
- IV. Open the phone bluetooth,search for the matching name for another bluetooth speaker and connect it
- V. Two bluetooth speakers were connected successfully,and can start playing music

Remark:

1. Two bluetooth speakers that already connected successfully,can automatic connect another bluetooth speaker when open the speaker again
- 2.If no automatic connection,please turn off the bluetooth,restart two speakers(didn't need press any key)
3. When the two speakers automatic connect,open the phone bluetooth again and connect the two bluetooth speakers