Smart Watch Phone

User Guide

Please read the manual before use

a click if the drag distance too short 2.3 Clock Display







Setting method:

method 1: Power on, whiten the phone in clock mode, please click middle screen and set different clock interfaces if you like.

method 2: Power on. Main menu: setting-phone setting-standby menu display-unjock selection, chock made if you like.

2.4 Product theme settings







10:02

harmonious

colorful


1. Safety Warning

- 1.1 The information in this document won't be modified or extended in accordance with any notice.
- 1.2 The watch should be charging 2 hours at least before use.
- 1.3 The original code is 1122, this code can prevent your watch in use by others without your permission.

Please change the original code to insure your personal information safe.

2.Product details

2.1 Product details



Power button: Power on / off, Awaken / turn off screen. Back to main

USB port: Charging / Data;

Touch screen: each function (main menu) will be shown and displayed on capacitive touch screen.

2.2 Products quick into

You can enter into next page by sliding screen to the left, and return to last page by sliding screen right, enter into the notice board after sliding from up to down, and return to main mean from down to up. It is will be in mistake for

Setting Method:

Main menu: Theme setting, choose the theme if you like

3.Product Quick use

3.1 Download the sync software

Scan or code , down load the APP which can match your android phone. This APP oliny use for the Syne between watch and phone, will not take your phone GPRS

If you already download the related softwares, please check the version and use the newest related softwares in order to ensure all function normal use. Please update the software when it has new one.

3.2 install and use the sync software

Android Application installation:

Please install the android application in your smart phone. Your can storage it into your phone memory or install by Sync assistant.

Android applications usage: (already installed)

(Smart phone) Setting - Accessibility - Enter into Bluetooth notice (service), enabled this service. (please choose "sure" when shown a warning notices) the application runs on the background automatically and syne function will be switched on as belw:





Click the Bluetooth notice and choose the Notification service, select you Personal or System application in Notify application

Telephone service in including SMS, incoming call and seek watch.

Mode:

Please don't shut the Bluetooth notify when you are clearing software by background or close background application software. It will affect the Sync function between watch and phone if shut it.

3.3 Bluetooth connectivity and sync function

3.3.1 From phone to Watch

Phone settings - turn on bluetooth - search for devices, please click pair devices wher found DZ09, and also choose "yes" in your mobile phone paired done.

Please choose "sure" when there is phone book request, meanwhile you'c better choose "no remind again", this is convenience when you connect next time (without remind again).

Notice: The Sync software can open in sync APP already installed and accessibility, the mobile will show Bluetooth connected done after 2-5 min.

the watch will inform you the time of Sync with phone, than the Sync Switched on. The message will sync to you watch when it incoming to mobile

3.3.2 From watch to phone

BT Dialer on DZ09-Search new device-found your smart watch (such as s9500)-connect. The processes of next are same with 3.3.1

Note: At the same time, the mobile phone need turn on the bluetooth and allow to be searched by around bluetooth products.

3.4 Base function

3.4.1 Message

Sync phones or watch message.

3.4.2 Bluetooth:

Set the Bluetooth, turn on / off.

3.4.3 Call records

You can check your phone call records after you connect with the Bluetooth. Shown all records including miss call, dialed calls and receive call; You can check the date, time and phone number of the miss call after you choose it, but only can call this number.

3.4.4 BT Dialer

Paired devices from smart watch

3,4.5 Remote Notifier

When there is SMS, incoming messages from QQ and other applications on the connected phone, the watch phone will alert you to read them.

3.4.6 Remote cameras

Use phone camera take pictures; but remote by watch, its need switch on the camera of phone in advance.

3.4.7 Anti lost

4

5

Watch seek phone, or phone seek watch.

3 4 8 Setting

Notice-sets clocks display and theme in phone setting; in the security Settings, the safe code is 1122

3.4.9 Pedometer

It can be adopted as a tool to avoid insufficient or excessive exercise by measuring calories of calories consumption based on collected data, such as number of steps, distance, speed, time, etc to control exercise.

If you want return to main menu but keep pedometer during the exercise, please press the power button.

3.4.10 Sleep Monitoring

Show your sleep quality base on your sleep times.

3.4.11 Sedentary Remind

You can set a time to remind you up to do some exercise, we suggest you this time could be one hours.

3.4.12 Quick response:

It can download sync software when scan the quick response, if there is a new version need to update, please contact with our servicer, our company will provide a new link for your download

3.4.13 Smart search

Searching information about watch

- 3.4.14 Alarm
- 3.4.15 Calendar
- 3.4.16 Calculator
- 3.4.17 Profiles
- 3.4.18 File Manager
- 3.4.19 Audio Player

Can play music from local or smart phone after connected with bluetooth;

- 3.4.20 Theme Settings
- 3.4.21 Camera
- 3.4.22 Video recording
- 3.4.23 Image viewer
- 3.4.24 Video Player
- 3.4.25 Sounder recorder 3.4.26 Phone OO

QQ need your phone has SIM card and can surf the Internet. 3.4.27 Browser

Browser need your phone has SIM-card and surf the Internet 3.4.28 SIM tool

4 Notice

- 4.1 Full charge before use, the charge time need 1-2hours.
- 4.2 Use the accessories cable and charger, or your android phone accessories
- 4.3 Bluetooth will disconnect when exceed the distance, after switch on the Anti lost, the smart search function can't be use before reconnect with
- 4.4 Please reconnect with BT if it's disconnected occasionally (please Manual connect if the Bluetooth over 5 minutes), please agree the phone book sync Otherwisethere is no called phone book:
- 4.5 When playing the music, some of music's name can shown and some can't, it is normal, because android phone are difference

5. Common Trouble shooting

Please refer below key function for any problems with the watch, if the problem is still unsolved, please contact with our dealer or serviceman appointed.

5.1 Unable to switch on

The time of press the power button too short, please keep it more than 3 seconds.

Low power, please charge it.

5.2 Shut down automatic

Low Power, please charge the watch.

5.3 Using time too short

Battlery is not full, please make sure it is full power(full charge need 2 hours at least).

During the use of SIM card, the power will be run off soon if the signal too poor.

5.4 Unable to charge

The battery's life will be reduce after few years, please check if the battery are work

Change a new charger if it is unworkable.

Please check the USB slot connecting good, if no, please try again,

5.5 Not caller's name when incoming call

Forgot to choose upload the phone book when connected with BT, or unselected keep upload the phone book.

Forgot to sync the phone book when reconnected, please pair the device and connect BT again

5.6 Bad phone call voice

watch and phone are separated too far, please be more close; Bad signal of BT. Bad signal of your own phone call place, please change a more better place for phone call.

Warranty Card				
Customer Information				
Model		Selling company	(signature)	
Customer Name		Phone NO.		
Sales Tet		Purchase Date		
Product IME: code				
Customer Address				
Sale Address				
	Summary			
Date	Symptoms	Servicing	Remark	