

Smart Bracelet User Manual



1. Introduction of Bracelet Function Interfaces

- 1.1 Time
- 1.2 Steps Counting
- 1.3 Distance Calculation
- 1.4 Calories Burned
- 1.5 Heart Rate Monitoring
- 1.6 Blood pressure
- 1.7 Battery Display

2. Bracelet Brief Operation

2.1 Display Touch Screen
Short Press: Activate the touch screen, and switch to different function interfaces;

2.2 Battery Charging

☆ Follow the Figure as shown, correctly clamp the bracelet with the charging clip, and it will be in the charging status as the pin connected to the charging point.
☆ When charging, the number of power grids displayed on the screen will increase until the bracelet is fully charged.
☆ It can be charged by DC power or PC when the bracelet is switched on/off.

2.3 Health Data Tracking

The steps counting and sleep monitoring functions are enabled by default. Tap the touch key to enter heart rate interface, the bracelet indicator will light up and heart rate monitoring function will be turned on. The bracelet synchronizes data automatically in real time to the smartphone after APK Bluetooth connected successfully. The sync data includes: steps / sleep / heart rate. You can tap to view the monthly health data report, and APK home interface can synchronize to display the battery level of the bracelet.

☆ Steps: The steps counting data is cleared at 0:00 every night.
☆ Sleep: The bracelet does not display the sleep mode as this function is run in background. The sleep data generated at night on the bracelet can be synchronized to your smartphone APK via Bluetooth connection on the next day. (NOTE: The sleep mode is enabled by default from 21:00 to 9:00 of next day. If the sleep tracking starts before 0:00 at night, the bracelet is displayed the same sleep date; if the sleep tracking starts later than 0:00 am, the sleep date is marked as next date. The data sync is based on bracelet binding with APK.

2.4 Bluetooth Connection

- 2.4.1 Download the APP
 1. The APP is available on Application Market.
 - Android: Please search and download the APP "Fundo Bracelet" (手动手环) via MyApp or SnapPea.
 - IOS: Please search and download the APP "Fundo Bracelet" (手动手环) via App Store.
2. Scan the QR code and download



Android: Scan the QR code through QQ, WeChat or other applications, and it will jump and turn to the download page to download the APP;
IOS: Scan the QR code through QQ, WeChat or other applications, then jump and turn to the download page by QQ browser or Safari to download the APP. (direct linkage to App Store)



The APP name on the Android device: "Fundo Bracelet" (手动手环)
The APP name on the IOS device: "Fundo Bracelet" (手动手环)
The icon is shown as the Figure when the installation is completed.

2.4.2 Login / Register

Select login by mailbox or the third party (QQ / WeChat).
Set up a new account firstly if login by mailbox.

2.4.3 Bluetooth Connection

☆ The Bluetooth is always in search state after the bracelet is turned on. When there is a successful login on the APK, tap the Bluetooth connection, select the bracelet device name (QS-80), and tap to connect.
☆ As Bluetooth connection is succeeded, the time will be synchronized between bracelet and smartphone. Tap to find the bracelet on APK, the bracelet screen will stay on with vibration effect, and the icon will be displayed.

☆ Bluetooth Auto-Reconnect:

1. No alert on the bracelet as Bluetooth connection is out of range. But when a bracelet is within the range, open APK and the Bluetooth will automatically reconnect.
2. Close the APP or restart the smartphone or tap One Key Clean-up, then open the APP again. The Bluetooth will automatically reconnect within the effective range.

3. Other Functions

The following functions can be achieved on the premise of a successful APK login and Bluetooth connection.

3.1 Notification Reminder

Android: Includes call reminder, SMS message reminder, QQ message reminder, WeChat message reminder (example: When the call reminder function is enabled, you will be notified with incoming calls via vibration, and the interface will display the call icon, you may stop the reminder by tapping the touch key)
IOS: Only supports call reminder function.



3.4 Alarm Clock

Tap the alarm clock setting to add a time on the APK. When the preset time is reached, the bracelet will vibrate to remind you with reminder icon display.

3.5 Reminder Mode:

☆ Screen-on: The bracelet only reminds you with screen lit up, as the alarm time you've set on your smartphone APK is reached or the push notification is received;
☆ Vibration: The bracelet only reminds you with vibration effect, as the alarm time you've set on your smartphone APK is reached or the push notification is received;
☆ Screen-on + Vibration: The bracelet vibrates to remind you and screen stays on, as the alarm time you've set on your smartphone APK is reached or the push notification is received.

3.6 Smart Gesture Control

Choose ways to wear (left hand / right hand), wear the bracelet on the selected hand (left hand / right hand):
☆ Lighting screen by hands raise: After the function is enabled, raise hands and place inner slant side of the bracelet in front of you, and the screen will be on.
☆ Lighting screen by turning over the wrist: After the function is enabled, turn your wrist over about 90 degrees and place inner slant side of the bracelet in front of you, and the screen will be on.

3.7 Unbinding Devices

Open the APP, tap Unbind Devices on the "I" interface, and it will prompt "Are you sure to unbind the Bluetooth device?", then select "OK" to unbind (All the operations must be under a successful Bluetooth connection)

Caution:

1. Bluetooth 4.0: Well compatible with Android 4.3, iOS 7.0 or later;
2. Please connect the charger to activate the bracelet for the first use;
3. If account login failure happened, please try to switch other account or log-in mode (QQ, WeChat, mailbox), and make sure the network connectivity is normal and stable.
4. Bluetooth connection:
 - A. Make sure the Bluetooth function is activated on your smartphone, and the bracelet is powered on;
 - B. When searching for Bluetooth, make sure the bracelet is not bound by other accounts;
 - C. When searching for Bluetooth, keep a connection distance as closer as possible between the bracelet and smartphone.
5. If the bracelet does not receive the push notification, make sure the APP is run in background and notification reminder is turned on (The auxiliary function needs to be enabled as well).
6. If the data of sports, sleep and heart rate are not synchronized to the APK, try to disconnect and re-connect the Bluetooth.
7. If you plan to bind the bracelet with another account, please unbind the current account first.
8. If the screen fails to stay on, please connect the bracelet to the charger.

Battery specifications

Material: polymer li-ion battery
model: PL 311222
Capacity: 70mAh voltage: 3.8V/4.35V electric current: 0.26 Wh

Warranty Card

Customer Name	
Phone NO.	
Purchase Date	
Sales Address	
Selling company	
Model	
Product IMEI code	

▲ Notice: 3.2 and 3.3 function closed

The company reserves the right to make changes to the contents of this manual without an notice. Some of the features in the specific software are different for the normal situation.

Warranty description

- This warranty card please safekeeping, to do maintenance certificate.
- Within 12 months of warranty period from the date of purchase.
- Equipment warranty within the warranty period under normal use and service, machine parts materials There is a problem, and the function of fault inspection is true, the company will provide free repair and Replacement parts.

The following are not free repair

The company's products shall be limited warranty within the warranty period. The equipment is under the following circumstances: Avoidance or damage, not in the scope of warranty (although in product warranty), the company does not undertake Warranty obligations.

- Equipment, components have been beyond the warranty period;
- The customer is not in accordance with the specification requirements,
- installation error, storage and use of equipment malfunction or damage;
- The company by non authorized agencies, personnel and equipment malfunction or damage of disassembly;
- Because of unexpected factors or reasons (including error, scratch, handling, not losing a bump) The appropriate voltage and current) equipment failure or damage;
- Due to natural disasters such as force majeure (such as earthquake, fire) equipment malfunction or damage caused by;
- The user to alter, tear up the product bar code;

Repair instructions

Over the free warranty period and not within the warranty period of the equipment regulations, the company can also provide Repair service, but the need to collect and repair costs.

Thank you
for choosing smart band
!