

User Manual for Smart Watch

Please check the list of following when you open the box



- 1.Smart watch*1
- 2.Magnet charger cable*1
- 3.Screw driver*1
- 4.User manual*1

First Boot

Press the power key for 2s shows the boot screen.At first time smart device need to test all the applications will take longer time, please be patient.After watch turns on,you can select the language you need,then start to setting the height/weight and moving target.After that,scan the QR code on smart watch and download WuiWatch smart phone. When select the wrong language,enter into Settings-Language and Input-Language, to correct the language.

Smart Watch Charging

Please charge the watch when it's out of power;The charger is magnet, when need charge, connect the magnet stand with the charger junction on battery cover(please find the picture following), data can be exchanged by using this magnet stand also.



Return Key

- 1.Short press the button when in the menu interface to turn back to previous menu.
- 2.Long press the button in the menu interface enter into the smart band mode, under smart band mode,long press the button return back to watch mode.
- 3.When the watch is charging, smart mode can't be used.

Sliding and Quick Access


Sliding up for weather condition on watch interface;
Sliding down for basic information on watch interface (battery capacity, time and date, SIMD card,APK connection status); Keep sliding left to the second menu(screen on/Vibrator,silent push,gestures awaken,flight mode, data,GPS,bluetooth,Wi-Fi).Users can choose to turn on or off the functions according to the demand.Keep sliding left enter into the pedometer interface to check the daily moving data;
On watch interface, sliding left enter into main menu, sliding right for sync messages;
In the secondary menu,sliding right to go back to previous interface.

SIM Card Installation

Please make sure to turn off the watch before put in the SIM card.Do as the following picture shows:

Open the SIM card cover with the screw driver, put in SIM card(confirm put the SIM card in correct direction) and lock the screw.

Please note that this watch only support NANO SIM card




Please pay attention to the direction of SIM card

Power Key Functions

Long press to turn on the watch;
Turn off the screen by short pressing;
Long pressing the key 2 seconds to enter into Power off/Reboot/Recent Task/Full/Small interface;
When in second menu,short press the power key to go back to main menu;
Long pressing 15 seconds to reset when watch crashed.

Full&Small Change Display Switch:

- 1.All the applications are working on smartphone and only suitable for square screen. round-square screen switch main function is to show the information on square screen which can't showed on round screen.
- 2.How to switch: open the application, when Confirm/Exit/Close functions can't display, long pressing the button 2seconds enter in Power off/Reboot/Recent Task/Full&Small interface,click the Full or Small watch icon at the top, when the icon change to square(writes small), press the button again to exit this interface. Enter into the application again and continue.



Menu Instruction and Operation Guide

Watch Face

- 1.There are different style watch faces for your option
- 2.Users can press the screen for 2seconds and enter into the watch face mode,choose anyone you like by sliding left and right.
- 3.Except the existed watch faces,sliding left to the end and press "+" to add more watch faces in the service when connect with the network.

Applications list:

The basic applications in the list included: Contacts,Phone, Messaging, Settings, Browser, Calendar, Clock, Camera, Gallery, Music, Sound Recorder, File Manager, Health, Weather, Voice Search, Play Store, Maps, Connect Phone, Remote Capture, Music Control, Find my device, Switch Platform

Application Functions Instruction:

Contact

Add, sync, delete all contacts;

Before sync contacts, please connect the watch to your phone via bluetooth, then sync the data until fulfill the data loading.

Phone/Call Record/Contact List

Input the phone number, press dial icon for dialing.

At dialing interface, slide left to enter into recent dial record

At call record interface, slide left to enter into contact list.

Messaging

Receive, read, reply and delete the messages.

Clock/Stopwatch

Users can set more than one alarm clock.

At alarm clock interface, sliding left to enter into stopwatch function, users can click "Start" for timing.

Sound Record

Touch record icon to start recording, after finishing the record, you can choose Save or Discard

Enter-in the recording list and choose the record to play

Calendar

Users can check the Gregorian, lunar and which day of the week

File Manager

Click the file manager, users can check the available memory. Click again can scan, add new, edit files.

With charge dock and USB cable, it can connect with computer and transfer or save the files

Browser

Users can use internet via WiFi or 3G network

Music

Users can choose Play, Pause, Next, press the icon on the top and adjust the voice volume.

Watch can play the music on bluetooth earphone.

There is no song in the music menu, you can download the songs by magnet charger and save in the music files.

Health

Click to enter into the Heart Rate/Pedometer interface.

Hear Rate:

Before enter into the heart rate menu, please make sure your are right

wearing the watch(best position is 1cm from your carpl bones),and a little tight on the wrist in case of light leak.After that, enter into heart rate monitor,keep your arm stable during monitoring,after seconds,users heart rate data will come out,click stop to finish the monitor(please don't exit the interface directly,or the heart rate will keep working).Sliding left can check the monitor record,sliding right return back to the last menu.

Pedometer:

Click to enter into the pedometer interface,users can see Steps/Interval Pedometer. Step is the default value of that day since the watch turn on pedometer,and will be zero clearing at 12pm.

Click the interval pedometer,it can count the steps withing the interval. Sliding left to enter into Calorie interface,convert the steps to calorie.In Calorie interface,sliding left to enter into step list interface,it include everyday sport data.

Camera

Click to enter into camera to take picture and video.

Suggest the users adjust the screen light to the highest for a better photo effect.

Gallery

Click to enter into the gallery,users can browser photos,videos.

Delete the photos--in the preview interface--touch the photo with two fingers, meanwhile slide the fingers to the middle of the photo--photo narrows--click the photo and slide up to delete.

Date&Time

When use network or GPS,default is automatic date&time.

Manual adjust date&time,please turn off automatic date and time zone, then set manually.Watch face will update date&time accordingly

Uninstall Application

Uninstall application software to release more memory space.

About Watch

Wireless Upgrade:Please make sure the watch has more than 50% power before upgrading and open wifi,don't use the watch when upgrading in case of failed upgrade.Turn on the watch after upgrade finished,as it need to check all the systems and applications,first boot will take around 10mins.After watch turns on, you can choose the language and start to use the watch.

WiiWatch Download

Android Users: Support original version 5.0 or higher(Setting-About-check the Android version)

iOS Users:Support ios9.0 or higher version(Setting-General-About to check iOS version)

How to download the WiiWatch for iOS and Android users:

Users can scan the QR code on Connect Phone interface, then install on phone

Android users: Search WiiWatch on Google Play and download

iPhone users: Search WiiWatch in APP Store and download.

Connect WiiWatch: Please understand the function operation in Connect Phone/Switch Platform.

Weather

It will update the local weather when have network.

Connect Phone/Switch Platform

Connect Phone: Users can scan the QR code in Connect Phone interface, and download WiiWatch on Phone.

Switch Platform: Before use the WiiWatch, please choose iOS or Android in switch platform

Remote Capture/Music Control/Find my device

Users can download the WiiWatch by scanning the QR code, after install and connect successful, can use the remote capture/music control and find my device

Setting

Sound,Display,App list style,Connect,Mobile assistant,Gesture,Power Saving, Language&Input,Date&Time,Reset equipment,Uninstall application,About watch.

Contact

Click connect menu,can turn on/off bluetooth,WiFi hot spot,fly mode,GPS and control the application data use at the background.

Gesture

Turn on/off screen on raising&Auto turn on pedometer.

Language&Input

Enter into Setting-Language,have many languages for option

Enter into keyboard,shift input method.

How to connect the WiiWatch for iPhone users:

- 1.Before connection: make sure both the bluetooth on smart phone and smart watch is turn on first, at the same time open WiiWatch APP (or you can't search the device)
- 2.How to connect:for the first time use, enter into menu and click Connect Phone, slide right to Search interface. Click the Search bar on the right top right corner, when WiiWatch address come out, click it and enter into connection interface,at this time, iPhone will receive a Paring request and choose pair.(if you can't search the WiiWatch address please exit and try again)
- 3.Connect many times or connected with Android before, please enter into main menu-Switch Platform and check if the platform it right (should be iOS)

How to connect the WiiWatch for Android users:

- 1.Before connection: make sure both the bluetooth on smart phone and smart watch is turn on first, at the same time open WiiWatch APP
- 2.How to connect:
 - a.Enter into main menu-Switch Platform and choose Android and click next step to restart the interface, choose OK to restart the watch.
 - b.Enter into WiiWatch and click the icon at the right button corner to enter into Setting-Device Management to enter into search interface ,Watch will receive a pairing request,choose pair(if you can search WiiWatch address, please clear all the addresses,exit and try again..

※The charger is magnet, please confirm the charger normal working before charging,no foreign body and dirty.

The battery can't be removed.Product itself has consumer,after one month no use may can't turn on because of no power,please charge the device each week to make sure it can work normally.

※Incorrect handling may cause device crashed, long press the power key for 15seconds to restart.

After a long time didn't use the device,when charging on computer USB port,it will take more than 10mins after showing the charging icon.We suggest users to use 5V/1A charger.