Smart Watch



User's Manual

Android 5.1















- 1. Watch x 1
 2. USB cable x 1 (Charging voltage/charging current: 5V/1A)
 3. Screwdriver x 1
 4. Manual x 1

Watch Charging with USB cable

Charge the watch before using it. Charging with USB Cable and connecting with computer.

Watch SIM card
Watch supports NANO SIM card. Through the watch, you can save a lot of contact and other personal information, including the PIN number, the contact list, short message and other additional system services.
Before inserting the SIM card, you should make sure that the watch is power off and open the back case with the provided screwdriver.

screwdriver.

Warning: Don't fold or scratch the NANO SIM card, and don't let it exposed to static, dust or liquor.



Power/lock screen button
Press and hold the button on the right to turn on / turn off the device and lock screen.

Press on 2 seconds out of the watch state shortcut set.

Crash problems, press on 10 seconds can be reset, equivalent to a battery

smart watch connect

Smart watch connect
Scan and download the APP on the smart watch, and then BT and
App connect to use the functions.
How to download: Settings-Mobile Assistant-Scanning-

Download and Install.

Slide up for Google Voice and Google fit: Run and walk

shed to be some state and sought that an about the sought that a speciment of the sought that a speciment of the sought that a specimen s



Watch Software and instructions

Home page and changing watch face

User stay on the home page. Tap and hold the screen for more than 2s and enter into editing mode to change different watch



Watch Application list

List included the basic application: Contacts, Messaging, Settings, Browser, Alarms, Music, Sound Recorder, File Manager, Weather and more







Replaceable Watch-faces

Various replaceable watch-faces, select the watch-face according to your taste.

Health

Heart-rate monitor

While you are wearing the watch, find and tap the Heart-rate icon to start monitoring.

Pedometer

While wearing the watch, find and tap the pedometer icon to start counting



Dial-un
Watch may record your loss. Touch your application of dial icon and enter into the nave of dial-un
Finter the nhone number (Area code may need for landline), then tan the call icon
Dial interface sliding to the left enter into the call logs, can call the call records list.
Call loss interface sliding to left again to the contact list. You can call who is in the list.

Messages
Touch "Messages" icon in the annlication list.
Touch the existing message to renly (SIM card).
Touch new icon to the edit new message. Input number, names or touch the icon into contacts, you can choose the contact to send messages. After enter the message, touch input box at the bottom

Contact
Touch the application list "Contacts" icon to enter the phonebook watch default first alphabetically by last name contacts.
Display only contact name in the phone book's home page.
The user can slide up and down to find the contact. The default
user storage location is "watch", support for reading the SIM
card contact.

Icon at the bottom of the function: Add contact.

Settines Include Sound, Display, Connect, Gesture, power saving, Language and Input, Reset equipment, Uninstall application and about equipment.

Watch Daily function application

Browser Access WIFI for searching.

GPS navigation
Google navigation or Baidu navigation.

Message notification
On home page, right slide to check pushed message.

Alarm Set the alarm clock.

Sound Record
Touch it's icon to start recording. Enter the recording list and choose the record to play.

Weather
Undate in real time through the network of local weather.
File Manager
You can see all the files of the Watch. You can also browse folders, add the new folder, edit etc.

Music
Watch built-in music player support for BT headset. Touch the music icon to enter music player.
Music player page displays are currently playing songs. Touch the middle icon to play or pause the song: touch above the speaker icon into the sound size adjustment: touch the middle icon on the left on the first play, touch the middle icon on the right side play the next song. After enter the playlist page, users can find their favorite according to his be fond of music, touch the song to play. the song to play.

Kevboard You can us

ou can use the English full keyboard.