

User Manual for Smart Watch

Please check the list of following when you open the box

- 1.Smart watch*1
- 2.Power bank *1
- 3.USB cable*1
- 4.User manual*1
- 5.Operation guideline*1

First Boot

- Press the power key for 2s shows the boot screen. At first time smart device need to test all the applications will take longer time, please be patient. After watch turns on, you can select the language you need, then moving forward.
- If users selected wrong language when turn on the watch, please enter into the Settings, choose Language and Input option then click the first one to change the language.

Smart Watch Charging

- First time use, please charge the watch when there is no power, watch is using contact charger, use USB cable to connect the power bank, also can connect with adapter or on computer USB interface.
- Users can fully charge the power bank and take the power bank along when they are out.

Power Key Functions

- Long press to turn on the watch;
- Turn off the screen by shot pressing;
- When in second menu, short press the power key to go back to main menu;
- Long pressing the key 2 seconds to enter into Power off/Reboot/Recent Task/Full/Small interface;
- Long pressing 10 seconds to reset when watch crashed.

Sliding and Quick Access

- Sliding up for pedometer interface on watch face interface; then sliding left to Distance/Calorie interface; sliding right to Steps, Distance, Calorie interface this week;
- Sliding down for basic information on watch face (battery power, time and date, SIM card, APK connection status); Keep sliding left to the second menu (DND mode, screen luminance, gestures awaken, flight mode, data, GPS, bluetooth, Wi-Fi);
- Users can choose to turn on or off the functions according to the demand. Slide left enter into the music interface, keep sliding left to weather condition;
- On watch face, sliding right for sync messages; sliding left enter into main menu, Keep sliding left to Multi- sport modes.

Full&Small Change Display Switch

1. All the applications are working on smart phone and only suitable for square

Applications list

The basic applications in the list included: Contacts, Phone, Messaging, Settings, Browser, downloads, Calendar, Clock, Gallery, Music, Sound Recorder, File Manager, fitness, Weather, Voice Search, Play Store, Maps, Camera, Heart Rate monitor, Mobile assistant.

Application Functions Instruction

Contact

Add, sync, delete all contacts;
Before sync contacts, please connect the watch to your phone via bluetooth, then sync the data until fulfill the data loading.

Phone/Call/Record/Contact List

Input the phone number, press dial icon for dialing;
At dialing interface, slide left to enter into recent dial record;
At call record interface, slide left to enter into contact list.

Messaging

Receive, read, reply and delete the messages.

Browser


Users can use internet via WiFi or 4G network.

Download

Users can review and delete the files downloaded by browser.


Calendar

Users can check the Gregorian, lunar and which day of the week.



SIM Card Installation


- Please make sure the smart watch is turn off before put in the SIM card. Do as the following picture shows; open the back cover with the screw, put in SIM card and lock;



- Please note that this watch only support NANO SIM card.

round-square screen switch main function is to show the information on square screen which can't showed on round screen.

2. How to switch: open the application, when Confirm/Exit/Close functions can't display, long pressing the button 2 seconds enter in Power off/Reboot/Recent Task/Full&Small interface, click the Full or Small watch icon at the top, when the icon change to square (writes small), press the button again to exit this interface. Enter into the application again and continue.



Menu Instruction and Operation Guide

Watch Face

1. There are different style watch faces for your option.
2. Users can press the screen for 2 seconds when watch interface then enter into the watch face mode, choose anyone you like by sliding left and right.
3. Except the existed watch faces, sliding left to the end and press "+" to add more watch faces in the service when connect with the network.

Clock/Timer/Stopwatch/Alarm

Users can enter into check different time zone & date
Sliding left to enter into timer function, users can click "Start" for timing;
keeping sliding left enter into for stopwatch, users can click "Start" for stopwatch;
Slide right to alarm, you can set several custom alarms.

Gallery

Click to enter into the gallery, users can browser photos, videos.
Delete the photos—click the photo and slide up to delete.

Music

- Users can choose Play, Pause, Next, press the volume icon and adjust the voice volume. can choose Play the song randomly/repeatedly.
- Watch can play the music via Bluetooth earphone.
- There is no song in the music menu, you can download the songs from computer and save in the music files.

Sound Record

- Touch record icon to start recording, after finishing the record, you can choose Save or Discard;
- Enter-in the recording list and choose the record to play, long press selected recording to delete.

File

- While Watch connecting power bank and use USB cable connect with computer,it can transfer or save the files.
- Click the file manager,users can check the available memory.
- Click again can scan,add new,edit files.

Multi-sport mode

Multi-sport mode including Outdoor run,outdoor work,indoor run,ride bike,play basketball,play football,play ping-pong,play badminton,rope skipping;Enter into those mode can set target time/target distance/target calorie,sliding left can view or delete data.

Weather

It will update the local weather when have network.

Camera

Click to enter into camera to take picture and video.
Suggest the users adjust the screen light to the highest for a better photo effect.

Hear Rate

Before enter into the heart rate menu,please make sure your are right wearing the watch(best position is 1cm from your carpl bones),and a little tight on the wrist in case of light leak.After that,enter into heart rate monitor,keep your arm stable during monitoring,after seconds,users heart rate data will come out,click stop to

Language&Input

- Enter into Setting-Language,have many languages for option,add needed language then long press it and move up to the first row;in this way to switch language.
- Enter into Virtual keyboard -Manage keyboard to add input,support Google voice typing and watch IME,note two input cannot be used at the same time.

Date&Time

- When use network or GPS,default is automatic date&time.
- Manual adjust date&time,please turn off automatic date and time zone,then set manually.Watch face will update date&time accordingly.

Reset equipment

Factory date reset as user's demand.

Uninstall Application

Uninstall application software to release more memory space.

About Watch

- Enter into about watch,developer options,status ,model number,android version ,etc.
- Wireless Upgrade:** Please make sure the watch has more than 50% power before upgrading and open wifi,don't use the watch when upgrading in case of failed upgrade.Turn on the watch after upgrade finished,as it need to check all

3. Remote Music/find my device /remote dialler,screen on raising,notification function would be available after connected.
4. On APK interface click health to view sport data,heart rate data,APK will record heart rate data.
5. Click sport interface can switch sport mode.
6. Click watch interface can download new watch face,iphone don't support download watch face by App.

Tips

- The charger is magnet, please confirm the charger normal working before charging,no foreign body and dirty.
The battery can't be removed.Product itself has consumer,after one month no use may can't turn on because of no power,please charge the device each week to make sure it can work normally.
- After a long time didn't use the device,when charging on computer USB port,it will take more than 10mins after showing the charging icon.We suggest users to use 5V/1A charger.
- Incorrect handling may cause device crashed, long press the power key for 10 seconds to restart.

finish the monitor(please don't exit the interface directly,or the heart rate will keep working).Sliding left can check the monitor record.

Mobile assistant

APK Download/Remote Camera/Remote Music/Find my device

Users can use these functions after scan Mobile assistant QR code to download/install/connect with APK successfully.

Setting

Sound,Display,App list style,Connect,Gesture,Power Saving,Language&Input, Date&Time,Reset equipment,Uninstall application, more ,about watch,etc.

Sound

To customize the media volume ,ring volume,alarm volume etc.

Display

To customize screen brightness and backlight off time.

App list style

Users can choose Arc style or Round.

Connect

Bluetooth,WiFi,Wifi hot spot,USB,fly mode,GPS.cellular networks,background data etc.

Gesture

Turn on/off screen on raising& pedometer service.

the systems and applications,first boot will take around 10mins.After watch turns on, you can choose the language and start to use the watch.

APK Download

Android Users: Support original version 6.0 or higher(Setting-About-check the Android version);

IOS Users:Support ios 11.1. or higher version(Setting-General-About to check iOS version,if the version lower than 11.1, please upgrade to11.1 or higher).

How to download the APK for iOS and Android users

From the watch: Setting-Mobile assistant-scan the QR code to download

IOS users: download the "wiiwatch2" in APP Store;

Android users: download the "wiiwatch2" in Google Play Store.

Mobile assistant connect APK

- 1.Both turn on bluetooth on watch and phone;
2. Use Wiiwatch2 scan Mobile assistant QR code,connect successfully will pops up on a paring request and choose pair,APK interface will show watch connected with phone