


User Manual for Smart Watch



User Manual for Smart Watch

1. smart watch phone *1
2. smart watch phone charging dock*1
3. USB cable*1
4. Screw driver*1
5. User manual*1

First Boot


Press the power key for 2s shows the boot screen. At first time smart device need to test all the applications will take longer time, please be patient. After watch turns on, you can select the language you need, then start to setting the height/weight and moving target.

Selected Wrong Language:


If users selected wrong language when turn on the watch, please enter into the Settings, choose the eighth option (Language and Input), then click the first one to change the language.

Smart Watch Charging

Please charge the watch when there is no power, watch is using contact charger. Attach the watch into the charging dock, then use USB cable to connect the charger dock and charge with adapter or on computer, data can be exchanged by using this dock also.



Charging Pin




USB Potr

SIM Card Installation

Please make sure the phone is turn off before put in the SIM card. Do as the following picture shows:

open the back cover with the screw, put in SIM card and lock. Please note that this watch only support NANO SIM card



Power Key Functions

Long press to turn on the watch;
Turn off the screen by shot pressing;

Long pressing the key 2 seconds to enter into Power off/Reboot/Recent Task/Full/Small interface;
When in second menu, short press the power key to go back to main menu;
Long pressing 10 seconds to reset when watch crashed.


Sliding and Quick Access

Sliding up for weather condition on watch interface;
Sliding down for basic information on watch interface (battery capacity, time and date, SIM card, APK connection status);
Keep sliding left to thesecond menu (screen on/Vibrator, silent push, gestures awaken, flight mode, data, GPS, bluetooth, Wi-Fi). Users can choose to turn on or off the functions according to the demand.
Keep sliding left enter into the pedometer interface to check the daily moving data;
On watch interface, sliding left enter into main menu, sliding right for sync messages;
In the secondary menu, sliding right to go back to previous interface.

Full&Small Change Display Switch:

1. All the applications are working on smartphone and only suitable for square screen. round-square screen switch main function is to show the information on square screen which can't showed on round screen.
2. How to switch: open the application, when Confirm/Exit/Close functions can't

display, long pressing the button 2seconds enter in Power off/Reboot/Recent Task/Full&Small interface, click the Full or Small watch icon at the top, when the icon change to square (writes small), press the button again to exit this interface. Enter into the application again and continue.



Menu Instruction and Operation Guide

Watch Face

1. There are different style watch faces for your option

- 2.Users can press the screen for 2seconds and enter into the watch face mode,choose anyone you like by sliding left and right.
- 3.Except the existed watch faces,sliding left to the end and press"+"to add more watch faces in the service when connect with the network.

Applications list:

The basic applications in the list included: Contacts,Phone, Messaging, Settings, Browser, Calendar, Clock, Camera, Gallery, Music, Sound Recorder, File Manager, Health, Weather, Voice Search, BT Call,Play Store, Maps, Connect Phone, Remote Capture, Music Control, Find my device, Switch Platform.

Application Functions Instruction:

Phone/Call/Record/Contact List

Input the phone number,press dial icon for dialing.

At dialing interface,slide left to enter into recent dial record.

At call record interface,slide left to enter into contact list.

Contact

Add,sync,delete all contacts;

Before sync contacts,please connect the watch to your phone via bluetooth,then sync the data until fulfill the data loading.

Messaging

Receive,read,reply and delete the messages.

- 2.Users can press the screen for 2seconds and enter into the watch face mode,choose anyone you like by sliding left and right.
- 3.Except the existed watch faces,sliding left to the end and press"+"to add more watch faces in the service when connect with the network.

Applications list:

The basic applications in the list included: Contacts,Phone, Messaging, Settings, Browser, Calendar, Clock, Camera, Gallery, Music, Sound Recorder, File Manager, Health, Weather, Voice Search, BT Call,Play Store, Maps, Connect Phone, Remote Capture, Music Control, Find my device, Switch Platform.

Application Functions Instruction:

Phone/Call/Record/Contact List

Input the phone number,press dial icon for dialing.

At dialing interface,slide left to enter into recent dial record.

At call record interface,slide left to enter into contact list.

Contact

Add,sync,delete all contacts;

Before sync contacts,please connect the watch to your phone via bluetooth,then sync the data until fulfill the data loading.

Messaging

Receive,read,reply and delete the messages.

Watch can play the music on bluetooth earphone.

There is no song in the music menu,you can download the songs from computer and save in the music files.

Health

Click to enter into the Heart Rate/Pedometer interface.

Hear Rate:

Before enter into the heart rate menu,please make sure your are right wearing the watch(best position is 1cm from your carpi bones),and a little tight on the wrist in case of light leak.After that, enter into heart ratemonitor,keep your arm stable during monitoring,after seconds, usersheart rate data will come out,click stop to finish the monitor(please don't exit the interface directly,or the heart rate will keep working).Sliding left cancheck the monitor record,sliding right return back to the last menu.

Pedometer:

Click the interval pedometer,it can count the steps withing the interval.Sliding left to enter into Calorie interface,convert the steps to calorie.InCalorie interface,sliding left to enter into step list interface,it includeeveryday sport data.Click to enter into the pedometer interface,users can see Steps/IntervalPedometer. Step is the default value of that day since the watch turn onpedometer,and will be zero clearing at 12pm.

Weather:

It will update the local weather when have network.

Clock/Stopwatch

Users can set more than one alarm clock.

At alarm clock interface,sliding left to enter into stopwatch function,userscan click"Start" for timing.

Sound Record

Touch record icon to start recording,after finishing the record,you can choose Save or Discard

Enter-in the recording list and choose the record to play.

Calendar

Users can check the Gregorian, lunar and which day of the week

File

Click the file manager,users can check the available memory.

Click againcan scan,add new,edit files.

With charge dock and USB cable,it can connect with computer and transfer or save the files.

Browser

Users can use internet via WiFi or 3G network

Music

Users can choose Play,Pause,Next,press the icon on the top and adjustthe voice volume.

Clock/Stopwatch

Users can set more than one alarm clock.

At alarm clock interface,sliding left to enter into stopwatch function,userscan click"Start" for timing.

Sound Record

Touch record icon to start recording,after finishing the record,you can choose Save or Discard

Enter-in the recording list and choose the record to play.

Calendar

Users can check the Gregorian, lunar and which day of the week

File

Click the file manager,users can check the available memory.

Click againcan scan,add new,edit files.

With charge dock and USB cable,it can connect with computer and transfer or save the files.

Browser

Users can use internet via WiFi or 3G network

Music

Users can choose Play,Pause,Next,press the icon on the top and adjustthe voice volume.

Camera:

Click to enter into camera to take picture and video.

Suggest the users adjust the screen light to the highest for a better photo effect.

Gallery:

Click to enter into the gallery,users can browser photos,videos.Delete the photos--in the preview interface--touch the photo with two fingers, meanwhile slide the fingers to the middle of the photo--photonarrows--click the photo and slide up to delete.

Remote Camera/Remote Music/Find:

MeUsers can use these functions after download/install/connect with the APK successfully.

Setting

Sound,Display,App list style,Connect,Mobile assistant,Gesture,PowerSaving, Language&Input,Date&Time,Reset equipment,Uninstall application,About watch.

Contact

Click connect menu,can turn on/off bluetooth,WiFi hot spot,fly mode,GPS.

Gesture

Turn on/off screen on raising&Auto turn on pedometer.

Language&Input

Enter into Setting-Language,have many languages for option

Enter into keyboard,shift input method.

Date&Time

When use network or GPS,default is automatic date&time.Manual adjust date&time,please turn off automatic date and time zone,then set manually. Watch face will update date&time accordingly

Uninstall Application

Uninstall application software to release more memory space.

About Watch

Wireless Upgrade:Please make sure the watch has more than 50% power before upgrading and open wifi,don't use the watch when upgrading in case of failed upgrade.Turn on the watch after upgradefinished,as it need to check all the systems and applications,first bootwill take around 10mins.After watch turns on, you can choose the language and start to use the watch.

Android/iOS Bluetooth Call Connection Guide

- a. Turn on Bluetooth on the phone, and stay on Bluetooth setting interface.
- b. Turn on Bluetooth call on the smart watch main menu interface, click 'confirm' to enter dial interface.
- c. Left slide to setting interface, click 'search',find the Bluetooth device name and click it to pair.
- d. Paring request pops up on the smart watch & phone separately, click 'paring' separately, after 1st paring, the smart watch would connect with phone automatically, or you could click 'connect' or click 'return'e.Bluetooth Call function would be available after connected.

How to connect the WiiWatch for Android users:

- 1.Before connection: make sure both the bluetooth on smart phone and smart watch is turn on first, at the same time open WiiWatch APP
- 2.How to connect:
 - a.Enter into main menu-Switch Platform and choose Android and click next step to restart the interface, choose OK to restart the watch.
 - b.Enter into WiiWatch and click the icon at the right button corner to enter into Setting-Device Management to enter into search interface ,Watch will receive a pairing request,choose pair(if you can search WiiWatch address, please clear all the addresses,exit and try again..

Tips:

- ※The charger is magnet, please confirm the charger normal working before charging,no foreign body and dirty.The battery can't be removed.Product itself has consumer,after one month no use may can't turn on because of no power, please charge the device each week to make sure it can work normally.
- ※Incorrect handling may cause device crashed, long press the power key for 15 seconds to restart.
- ※After a long time didn't use the device, when charging on computer USB port,it will take more than 10mins after showing the charging icon. We suggest users to use 5V/1A charger.

WiiWatch Download

Android Users: Support original version 5.0 or higher(Setting-About-check the Android version)

iOS Users:Support ios9.0 or higher version(Setting-General-About to check iOS version)

How to download the WiiWatch for iOS and Android users:

Users can scan the QR code on Connect Phone interface, then install on phone

Android users: Search WiiWatch on Google Play and download

iPhone users: Search WiiWatch in APP Store and download.

Connect WiiWatch: Please understand the function operation in Connect Phone/Switch Platform.

How to connect the WiiWatch for iPhone users:

- 1.Before connection: make sure both the bluetooth on smart phone and smart watch is turn on first, at the same time open WiiWatch APP (or you can't search the device)
- 2.How to connect:for the first time use, enter into menu and click Connect Phone, slide right to Search interface. Click the Search bar on the right top right corner, when WiiWatch address come out, click it and enter into connection interface,at this time, iPhone will receive a Paring request and choose pair.(if you can't search the WiiWatch address please exit and try again)
- 3.Connect many times or connected with Android before, please enter into main menu-Switch Platform and check if the platform it right (should be iOS)