Smart Watch User Manual

Thank you for choosing our company smart watch. You can read this manual to have a comprehensive understanding of the using of device and operate it simply. The company reserves the right to amend the contents of this manual without prior notice. Package: one gift box, one user manual, one smart watch, and one charging cable.

Charging: Flip face down the watch to charge, L2 with magnetic charging, support PC USB or cellphone 5V standard charger, 70min needed for full charging.

Caution: Do not make the magnetic charging cable may cause short circuit.

Watch connect to Cellphone, need download the App "Fundo" in the cellphone at very first, see below 2 methods.

a. Android/iOS Phone: Scan the QR code in the watch ("Setting" -App download) or scan following QR code image to Download "Fundo"



Android phone search "Fundo pro" in Play Store, iOS phone search "Fundo pro" in Apps Store.

After installation, turn on cellphone Bluetooth and Fundo App, confirm the notification enable, tap "More" at right bottom corner, enter add device, search "NJY-L2-LE" device and tap connect, then you are succeeding connected the Bluetooth 4.0; any 2 pins connect with conducting material at same time, it Next go to watch side Bluetooth-searching Bluetooth-select turn on Bluetooth-tap your cellphone name in the list-confirm the connection at your cellphone end. Then you are succeeding connected Bluetooth 3.0:

> Only when Bluetooth 3.0 & 4.0 both connected the watch can be abled full performance, slide down the watch you will see the Bluetooth icon, green color at upper means Bluetooth 3.0 is connected. Blue color at bottom means Bluetooth 4.0 is connected.

X Operation Guide

The top button: short press enter pedometer function to show the day steps, calories burned and distance walked.

The bottom button: Long press to switch watch, short press to return to the standby interface, when watch crashed, long press 10 seconds to restart.

TP gestures: slide right/left/up to enter the main menu, after entering each function, slip from left to right for return, slip from right to left for confirmation

Watch face switch: long press the screen, there will be a dial choice, tap confirm.

Status bar: slide down to enter, it tells Bluetooth status, battery life etc.

Main function

Calling

Dial: Bluetooth call via cellphone, talk at the watch end. Phonebook: Sync all the contacts in the cellphone, up to 400

Call logs: Sync all the calls history in the cellphone. SMS: Sync all the messages in the cellphone (Not support iOS phone yet).

Rluetooth: Search the device you want connect or disconnect the devices.

Notification: It will remind all the notifications from cellphone, such as Facebook, Email, WhatsApp, SMS etc. it has to connected with "Fundo" Apps first.

Health

Heart rate monitor: wear the watch tightly with your wrist, best position would be upper of the hand-wrist, around 20 seconds it will shows the real time heart rate data, slide down menu into history, mode includes single measure and continuous measure; and instruction.

Pedometer: check the steps you walked during the day, calories burn and walk distance. Everyday 0 o' clock all the data will be saved automatically and reset to 0. Slide up enter option; status, on and off; history, it can check 7 days local records; Goal, set a target for everyday steps; put into all your information, such as Gender, Height, Weight etc. for more accurate measure your steps data.

Sleep monitor: It records your sleep duration and quality, help

you adjust a better rest time, improve sleep quality. Slide up enter options; Status, On and Off; History, check out deep sleep and light sleep; instruction.

Sedentary: Set a long-time reminder of sit, remind you have a stand when time up.

Sport: Selecting the mode according to different sport type, more accurately monitor your exercise data; it includes walking, running, hiking, cycling, basketball, ping-pong, badminton, football, sex for choice. It shows heart rate data also.

Tools

Alarm: It is able to set multiple alarm clock.

Stopwatch: Single timing, tap the left icon to start timing, and tap to pause, tap again for cumulative time.

Calendar: Calculator.

Remote shot (while connected with cellphone): Turn on the camera in cellphone, turn the remote camera in the watch, take a photo by watch, photo save in cellphone side.

Music Player: Bluetooth Music is able to control the music playing in mobile.

Anti-lost: Tap "Start", the connected phone will be ringing warning, after find the phone, tap "End" of the phone to stop the alarm, it works both watch and Apps sides.

Setting

Bluetooth Setting: Turn on/off the Bluetooth in watch. Apps download: There is a OR code in this icon, scan it by cellphone to find the address download "Fundo" Apps. Clock: clock type, there are 4 standby watch faces to choose; Time synchronization: the default is on, after connecting to the phone will sync the phone time, if you want to manually adjust the time, you need turn it off;

Sound: you can select the caller profile, select Ringtones, select notification ringtones;

Volume: adjustable volume for media, ring tones, notifications, etc.;

Power-saving mode: turn watch on to enter clock mode, other functions are turned off; display, access to adjustable screen brightness and backlight off duration;

Multi-languages: Auto synchronization is turned on by default. After the mobile phone is connected, the mobile phone language will be synchronized. To manually select the language, turn it off;

Unit: select the data unit is metric or imperial;

Gesture: support for call turnover mute, alarm flip over mute, gesture wake up system (ie It is to raise the hand to automatically light screen), shake to answer the call;

Restore the factory settings: generally, if there is a software problem happens, restore the factory settings can be resolved;

About: you can view the watch model and software version.

Data transmission: mobile phone to download Fundo App, after the connection is successful, either steps data, heart rate data, the sleep quality, multiple sports can be transmitted to the mobile end.

Warranty instructions

Simple handling method: As the Bluetooth protocol of each mobile phone brand is not uniform, there may be cases where the Bluetooth connection between the mobile phone and the watch is unstable. The Bluetooth mobile phone may be turned off and then connected again, or the watch may be reset to factory settings, such as a watch. A crash occurs and you can press and hold the key for 10 seconds to restart the watch.

Warranty

- 1. If it appears quality problems caused by manufacturing, materials, design within one year (since the day of purchase), battery and cable within 6 months. we will offer free warranty. Premise is using normally and correctly.
- 2. About the fault caused by the user's personal reasons, we don't offer free warranty, as follows:
- 1). Disassemble or refit the product.
- 2). Caused by immodesty drop
- 3). All artificial damage or misuse (such as: make water into the host, the external force shatter, scratch damage of peripheral components, etc.), all these are beyond the scope of the warranty.
- 3. When ask for free warranty, you must provide a warranty card with the seal of purchase place and purchase date.
- 4. If you met problems during use, please contact the shop customer service which you bought from.
- 5. Please make the final products as the standard. Date of purchase:

IMEI code:

Buy store: