

Smart Watch



Android Smart Watch

Packing List:

- 1*Smart Watch
- 1*USB cable
- 1*Screwdriver
- 1*User Manual

USB Charging Cable

Charging and data transferring.

SIM Card

Support NANO SIM Card; PIN code, phone books, messages and other data can be saved in the SIM card. Before making phone calls, please make sure the watch is turned off. Open the back case with specialized screwdriver and install SIM card to the slot.

Note: Don't twist or scratch NANO SIM card
Don't let it contact with static electricity, dust and water



Power / Lock Screen

The button on the upper right implement function such as poweron/off, lock screen, bright screen

Longpress 10s to restart the watch.

The button on the lower right is sports mode shortcut key.




poweron/off,
lock screen,
bright screen

sports mode
shortcut key

Before Use

Turn on the watch, follow the prompts to download APP for connection and pairing.

Quick Guide



Multiple Dial Options

You can choose multiple dials by long press the screen on the dial homepage or download more dials with internet connection.



Software

Basic softwares such as Address books, Telephone Books, Messages, Settings, Internet, Clock, Calendar, Music, Voice recorder, Files, Weather and so on.



Health Data Track

Heart Rate Monitor

Wear the watch, turn on heart rate monitor function and your real-time heart rate data will be shown.



User Manual




Diverse Sports Mode

The button on the lower right is sports mode shortcut key.



Pedometer

Wear the watch, turn on pedometer function and your steps will be recorded and shown.



Dial-up call function

Recording your incoming, outgoing and missed calls when sim card is inserted.

Message function

1. click "Message" to enter Message function interface.
 2. click existing messages to respond.
- click "Compose" to edit new messages, enter telephone number, name in the "recipient" zone or click portrait to enter telephone book and choose contacts. Input information content in the "Enter message" zone.

Telephone Book

Contacts are listed alphabetically and only names are displayed on the telephone book first page.

Users can find contacts by sliding. The default storage location is watch and support read SIM card contacts.

Bottom icon on the Contacts: Add contacts.

Setting

Sound, Display, Connection, Power saving, Language and input method, uninstall application, About watch.

Daily Function

Internet

WiFi, 3G, 4G network fast logging.

GPS

Google map or baidu map navigation.

Alarm Clock

Set alarm

Voice-recorder

Click "record" to start record, click "Save" to save record and click "Discard" to discard record.

Enter record file list and play current record.

Weather

Update weather in real time when network is connected.



Music player

Built-in music player, support bluetooth earphone play

Currently playing music is displayed on Music player interface, click icon in the middle to play or stop music, click loudspeaker icon on the top to modulate voice, click left icon to play previous song, click right icon to play next song.

Input method

Qwerty keyboard is supported, keyboards can be switched by setting language and input.

Camera

Click "Camera" to enter camera function. Users can take photos and video.

Gallery

View photos, videos