

## Device Structure

1. This device is composed of a smart bracelet and two TWS earbuds. Open the cover of bracelet and then two earbuds are exposed.



2. How to pair two earbuds

There are two earbuds, one is L (left ear) and the other is R (right ear)

The two earbuds is already paired in factory. When taken out from bracelet and all two earbuds are ALL powered on, if only the *Earbud L* is flashing with green light, this indicate that the two earbuds is paired already. In this case, power on your smart device's BT to

press the touch button "⌘" for 3 seconds to shut down.

3. Counting steps

Click the touch key "⌘" on the main interface of the device to enter the motion interface, display the current number of steps, and automatically stop the screen after 5 seconds without no operation.



4. Distance

Click the touch key "⌘" on the main interface of the device to enter the motion interface, display the current distance, and automatically stop the screen after 5 seconds without no operation.

5. Calories

Click the touch key "⌘" on the main interface of the device to enter the motion interface, display the calories currently consumed, and automatically stop the screen after 5 seconds without no operation.

6. Heart rate

Click the fourth touch key "⌘" on the main interface of the device to enter the heart rate detection interface and start detection. After measuring the result, the real-time heart rate value will be continuously measured and displayed. Regardless of whether the result is measured or not, the device will automatically off the screen after 60 seconds of cumulative test. The heart rate measured on the device will not be saved.



7. Blood pressure

Click touch key "⌘" on the main interface of the device to enter the blood pressure manual test interface and start the test. The time required to measure the result is different due to the user's physical condition. Please be patient.

During the test, the blood pressure is displayed as "x/x". If the blood pressure cannot be measured, it will be displayed as "x/x/xxx". Please check whether the sensor of the device is completely close to the skin. Please keep your body relaxed and still during the test. Regardless of whether the result is measured or not, the device automatically go to standby in 70 seconds. The blood pressure values measured on the device will not be saved.

detach earbuds with BT name WY-L and connect it. After that your smart device is connect with two earbuds successfully. And two earbuds can hear voice at the same time.

After earbuds are connected with smart device like smart phone or tablet, they will not flash any more.

Why I hear only one earbud?

Please make sure all two earbuds are on and your smart device connect with WY-L ( If connects with WY-R or only one earbud is on, only one could hear voice)

The two earbuds are not paired or fail to pair

What happen if two earbuds are not paired?

If not paired, only one earbud could hear voice. In your smart device, when you connect WY-L, only the Left earbud is working. When you connect with WY-R, only right earbud is working.

If two earbuds are not paired and ALL power on, you will see two earbuds are flashing with green light, or ONLY *Earbud R* is flashing with green light. Then the following step is required to pair them.

- (1) Close BT of smart phone
- (2) Press two earbuds round circle at the same time for 8 seconds to power them off, and release your fingers after 8 seconds
- (3) Press two earbuds round circle at the same time for at least 16 seconds and release fingers (during this process earbuds will power on and finally power off)
- (4) Press them at the same time again for 3 seconds to power on. You will see them power on and only Earbud L is flashing. This means they are paired successfully.
- (5) Open the BT of smart phone, search the BT name WY-L and connect it.

3. Packing list

Bracelet                      Gift Box\*1  
BT earphone\*2      Magnetic USB cable\*1                      User manual\*1

4. Charge

Bracelet charge: use magnetic USB cable to charge bracelet.

Earphone charge: Put the earphone into bracelet hosts, the bracelet will charge the earphones.

## Bracelet Connection and Main Function

1. Basic function

- (1) TWS stereo headphones
- (2) Heart rate monitor



8. Alarm clock

In the alarm setting interface of the APP, different alarms can be set.

9. Incoming message/calls reminder / push

When there is incoming message or calls, the device will vibrate and display the message content.

**Note:** Please enable the corresponding Application which you want to syn in the app first.

10. Sedentary reminder

This function needs to be turned on and set on the APP first. When the device detects that the wearer has reached the set value during the sitting or relatively stationary state, the vibration reminder is activated.

11. Remote photography

Enter the camera interface through the APP, press the touch button "⌘" or quickly shake the wrist, then smart phone will take photo.

12. To find the bracelet

In Kakafi app, there is a function to find the bracelet. Click on the button to find the bracelet. The motion on the bracelet will last for 5 to 10 seconds.

13. Raise wrist to wake up screen

Time interface This function needs to be opened and set on the APP first. When the device detects that the wearer's action of raising the wrist, it will wake up the bracelet in 3 seconds.

**Note:** The device needs to be connected to the APP, and the wrist display function is enabled.

## BT headset function instructions and precautions

1. Headset pairing

(1). Headset pairing: Take the earphone out of the wristband host, there is a power-on voice, turn on the BT in the phone settings, find the corresponding BT name (WY-L) and pair it with the connection. (The headset is already connected and the pairing is when manufacturing in the factory).

(2). After the headset is successfully paired, put it back into the wristband host, and then remove the headset from the wristband host to automatically power on and automatically connect.

(3). After the headset is successfully paired, if the phone is manually disconnected, you

- (3) Blood pressure

- (4) Step counting, mileage, consumption

- (5) Sleep monitoring, sedentary reminder, lifting wrist to wake up screen

- (6) Incoming message alert, phone call alert

- (7) Shake and take picture

3. APP download.

Install *Kakafi* by scanning QR code provided. Support iOS and android device.



4. BLE connection device and pairing

(1). BLE connection: Go to SettingsMy device. Then you could see the bracelet name and mac address. Choose the right address of your bracelet, click it. It will be bound when it connect successfully. Click it again it will unbound the bracelet.

(2). After the first binding is successful, the device will be automatically connected after the device is turned on within signal range

(3). If you would like to bind another bracelet to the APP, unbound the previous bound bracelet first.

5. Trouble shooting on failed connection

(1). Make sure the BT of the mobile phone is turned on;

(2). Make sure that the equipment is fully charged, please turn it on or charge before use;

(3). Make sure the device is within 50cm of the phone when pairing the connection;

(4). If your Android phone does not find the device in the mobile app, please check whether the "Kakafi" is allowed to use BT in your phone;

(5). When pairing the headphones, make sure that the headphones are taken out from the wristband host; if no BT is found, put the headphones into the wristband and take them out again to activate them.

## The main function of the bracelet (BLE)

✧ **Note:** To ensure that the data is accurate against your physical situation, please fill in the true gender, height, weight and age information of wearer in the profile of the app.

1. On/Off

When the device is turned off, press touch key "⌘" for 3 seconds to enter, and enter the time interface. After 5 seconds without operation, the device automatically goes off to standby.

Go to the device shutdown icon, click touch button "⌘" to choose OFF option, and then

need to reconnect with the BT of the phone.

(4). headset pairing: first turn off the two headphones, then long press the button 16S, release the hand, and then press the button at the same time will automatically complete the pairing. The BT function in the phone settings must be turned off for the connection.

2. The middle touch button of the earphone is a dedicated button for the BT earphone, which is used for answering incoming calls, rejecting incoming calls, muting calls, calling back.

3. Answer/hang up/reject calls

When the earphone is inside of the wristband and there is an incoming call, it will automatically pick up phone calls once it is taken out. If the earphone is outside of bracelet, and the incoming call needs to be manually answered.

Double-click the button to answer the call;

Double click again to hang up the phone;

Long press to reject the call;

During the call, once the earphone is turned off or disconnected with your phone, then your phone will be automatically take over to continue with that phone call.

4. Mute the call

While the headset is in a call, press and hold the touch button 3S to enter the mute the calling, then press and hold to return to the calling.

When the headset has an incoming call in the base of the bracelet, the device will vibrate and display a reminder. Touch the button area to remotely operate the manual mute. Press and hold the touch button for 3 seconds to reject it directly.

## Voice assistant and call

When the headset is connected, 3 touch the touch button to activate the Siri of the iPhone or Android voice assistant. The Siri or Android voice assistant can be activated only when the phone is on standby menu or time main menu.