

Smart watch

User Manual



LEADING A HEALTHY LIFESTYLE

• Smart watch •

Thank you for choosing our smart watch. You can read this manual to get a comprehensive understanding of the function and operation of the device. The company reserves the right to modify the contents of this manual without prior notice without prior notice.

Package: One gift box, one user manual, one smart band unit.

This product supports IP68 waterproof, it's available to wear it while wash hands, swim etc. Hot water shower or sauna cannot be worn to prevent steam. If the water is not used according to the instructions, the company will not make a free warranty.

Buttons Instruction:

Botton button:Long press the switch, then short press the screen to lighten the screen,charger to start on.

Changeable band:A small switch,push it in the middle, then can change the band.

• Smart watch •



Botton button

Touch instructions:Click enter and swipe right back, enter the status bar under the home screen, slide right to enter the notfication center, slide right to enter the main menu. slide up to enter the weather condition.

• Smart watch •



Charging instructions:

This product adopts magnetic force charging. Support within 5V mobile phone charger and computer USB interface. Put the charging point connect to the back of the device charging pins, it will charge automatically. It usually takes 2 hours to full charging, device standby time up to 30 days, 5-10 days for working. Do not use the watch when charging.

△ Caution: Do not make the magnetic charging cable any 2 pins connect with conducting material at same time, it may cause short circuit.

• Smart watch •

The connection between the watch and the mobile phone:

First, the mobile phone needs to download the APP "WearFit 2.0" to the mobile phone and install it, two ways



1. IOS, Android Mobile User:
Scan following QR code image by browsers or by any Scanner to Download WearFit 2.0.
2. Android Phone: search and download "WearFit 2.0" app from Google Play;IOS phone: search and download HPlusFit app from Apps Store.

After installation, turn on cellphone Bluetooth and "WearFit 2.0" App, confirm the notifications and all others permission "WearFit 2.0" asks are enabled, Bind bracelet, find "S20" device (Some phone brands need turn on the GPS in the smart phone before binding) and tap connect.

• Smart watch •

Firmware upgrade:

Under Bluetooth connected, in "WearFit 2.0", Tap Mine- "Device management" - "Firmware update", if there is new firmware available, click to update to the latest watch firmware version.

Notice: If it is unsuccessful to upgrade, please wait for the watch run out battery and charge reboot the watch again, search Bluetooth device Huntersun-BLE connect and upgrade again.

As the Bluetooth protocol is different between all the phone brands. Sometimes the Bluetooth connection will be instability between mobile phone and smart watch. Please restart the Bluetooth, then try to connect again.

Main function introduction:

Language/Time/Date: It will synchronize the date & time from the phone when Bluetooth is connected with App.

Standby watch face: There are couples watch faces for options, long press 2 seconds at home to change.

Status bar: Slide down enter the standby interface with Bluetooth status, QR code (scan with mobile phone and download "WearFit 2.0"), brightness adjustment and battery statue.

Notifications: Slide right into the notification, notifications synchronous from phone, such as calls, WhatsApp, SMS, WeChat messages, recent 8 alerts can be shown, when calls, messages coming, watch vibrate remind, support decline a call.

Pedometer、Distance、Calorie: Monitoring daily steps, mileage, calories. Reset at 0 o'clock each day. Support 7 days records data in the watch.

Sports: Multiple sports mode, select one to start, slide right to pause the exercise. It records duration, calorie consumption and heart rate etc. data.

Heath care

Heart rate: When this function is activated, the heart rate is being measured by the device scanning the surface capillary of the skin with green optical diodes. Please allow for about 2 seconds to start measuring and recording. Slide to other menus to stop measuring. Please refer to information about average heart rate, heart rate while exercising for your age group and gender online and/or ask your medical practitioner for advice.

Blood pressure: Please put your hands flat on a surface and do not move. When this function is activated it needs about 45 – 50 seconds of measuring and reading to provide a result.

Please note: The device is not a medical device. Any values shown are for reference only.

ECG:The device combines an optical heart rate sensor and ECG sensor to show information about the user's heart function for reference. When this function is activated it needs about 30 seconds of measuring and reading to provide a result.

Please note: The device is not a medical device. Any values shown are for reference only.

Blood Oxygen:Blood oxygen (SP02H) level is the amount of oxygen circulating in the blood. Please refer to information about healthy or abnormal blood oxygen percentage for your age group and gender online and/or ask your medical practitioner for advice.

Please note: The device is not a medical device. Any values shown are for reference only.

Sleep monitor:Sleep monitoring will be automatically active from 10:00pm to 8:00am the next morning. You can check the details of sleep quality with the WearFit2.0 app in the phone.

Stopwatch:Press the start and pause, again press for stop.

Remote control music:Play the music at phone side, control at the watch side.

Remote camera:Ener WearFit 2.0, tap + ente the camera function, shake the watch to take a photo.

About:Tap to enter, check device model, firmware version, Bluetooth address.

Reset:Recovery device.

Alarm:Set several alarm clocks through the App in the phone.

Sedentary Reminder:You can set time to remind yourself stand up.

Wrist bright screen:Set it in the App, it takes more power consumption when it is on.

Units Setup:Metric or British system.

Find your phone:Tap it and phone makes a ringtone alert.

Data transmission:All the data will be saved in the device. No matter pedometer, heart rate, sleep quality, and multi-sport mode, the data all can be transmitted to the APP in the phone.

Warranty:

1. If it appears quality problems caused by manufacturing, materials, design within one year (since the day of purchase) , we will offer free warranty for main part. We will offer free warranty for battery and adapter within 6 months. Premise is using normally and correctly.

2. About the fault caused by the users' personal reasons, we don't offer free warranty, as follows:

- 1). Disassemble or reft the product.
- 2). Caused by immodesty drop
- 3). All artificial damage or misuse (such as: make water into the host, the external force shatter, scratch damage of peripheral components, etc.), all these are beyond the scope of the warranty.

3. When ask for free warranty, you must provide a warranty card with the seal of purchase place and purchase date.
4. If you met problems during use, please contact the shop customer service which you bought from.
5. Please make the final products as the standard.

Date of purchase:	Customer signature:
IMEI code:	Clerk Signature:
Buy store:	Shop stamp: