# 3D Pedometer Watch User Manual (Model:W1P)



# Product Profile



High - sensitivity 3D acceleration sensor

Capture minor movement, more accurate step count



Exercise data memory It can be connected with computer to view the exercise data



USB port is integrated in watch band Plug and play



Real-time temperature display

Easy to know the temperature of the place wherever you are





Time / Date / Temperature: Touch the key, current time/date and temperature will appear in the screen.

[Tips] The sequence of display: Time/Date/Temperature. range of ambient temperature display: -10°C~50°C, 14°F~122°F(Fahrenheit degree).



Press pedometer: Press and hold the key for 3 seconds, the system will enter step count mode.

[Tips]

- Touch the key while in step count mode, you can shift the working mode between step count and timer.
- Press and hold the key for 3 seconds while in step count or timer mode, the system will exit current working mode.



Time setting: Touch the key, the system will enter current time display mode. While in the time display screen, press the key and hold it for 3 seconds, the system will enter time setup screen. [Tips]

- After entering time setting mode, touch the key to increase the number, press the key and hold it for 3 seconds to change adjustment options.
- The adjustment sequence: Hour > Minute > Month > Day > Year.
- The time can also be set synchronously with PC. (for details please refer to the instructions "Time setting with PC" On the right)
- For details of alarm setting please refer to the instructions "Time setting with PC"On the right.



Rechargeable

polymer battery

the device via USB port

Exchange data or charge

Time / Date / Alarm

The time synchronous to

computer, muting ringing

Trace calorie, moving

steps and distance

Allows for identifying the extent to which the exercise

goal has been accomplished

reminder

Display remaining power volume: When the device is at low power volume, the system will display the remaining power volume, reminding owner of charging the device.

[Tips]

- When power volume is less than 10%, touch the key, the system will automatically display remaining volume after time is displayed.
- Power volume will be displayed when the device is connected to PC.





# **Instructions Of AP Software**


### Personal basic information setting



## / Time setting with PC



## / Goal / Task setting



#### Career



### Statement



## / Specifications

Size	210×18×9mm (please refer to the original object)
Weight	29g(net weight)
Display	LED display
Range of temperature display	-10°C~50°C,14°F~122°F
Type of port	USB Port
Accuracy of step count	±5%
time error	error for 24H (±99s/day, adjustable by software)
Data memory	Able to continuously store up to 120 hours of step count data
Number of steps	0 - 9999 steps
Life of battery	Time of charge and discharge>300 times
Power voltage	DC=5V
Operating atmospheric pressure	860hPa ~1060hPa
Operating temperature	0 ∼ 45℃

AP download centre: www,123smartsport,com

Notes: AP supports multiple languages