

Smart Watch Phone

User Guide

Please read the manual before use.

- 1. Safety Warning
 - The information in this document won't be modified or extended in accordance with notice.
 - The watch should be charging 2 hours at least before use.
 - The original code is 1122. This code can prevent your watch in using by others without your permission.
 - Please change the original code to insure your personal information use.
- 2. Product details:
- 2.1 Product details

Hardware parameters	
CPU	MTK6261
Memory	32GB TF Card
Lcm	1.54" IPS LCD with 240*240 PIXEL
Touch Panel	2.5D with Arc type Capacitive Touch Panel ,and Non-air-gap
Bluetooth	BT3.0
Camera	2.0M
Battery	430mAH Large-capacity lithium polymer batteries
G-sensor	Pedometer, Sedentary remind, Sleep monitor, Anti lost, Remote camera

Feature list	
Call function	GSM/GPRS 850/900/1800/1900
	Dial, Hands-free calls, Call records and phonebook

1

	notification to watch
	Remind schedule synchronization
	Time synchronization

- 2.2 Products quick info
 - You can enter into next page by sliding screen to the left, enter option interface by clicking the screen, and return to last page by sliding screen right; .It is will be in mistake for a click if drag distance too short.
- 3. APK-download, install and quick use:
 - 3.1 Download the Sync software.
 - Scan QR code, download the APP which can match your android phone. This APP only use for the Sync between watch and phone, will not take your phone GPRS.
 - If you already download the related software, please check the version and use the latest related software in order to ensure all function normal use. Please update the software when it has new version.
 - 3.2 Install and use the Sync software
 - Android Application installation:
 - Please install the android application in your smart phone. You can storage it into your phone memory or install by Sync assistant.
 - Android application usage (already install)
 - (Smart phone) Setting -- Accessibility --Enter into Bluetooth notice (service). Enable this service. (Please choose "sure" when shown a warning notice) the application runs on the background automatically and sync function will be switched on as below.
 - Please open the Bluetooth notices in the applications of your smart phone and choose the Notification service, select your Personal or System

- 4.4.4 Calls records
 - You can check your phone call records after you connect with the Bluetooth.
 - Shown all records including miss call, dialed calls and receive call; You can check the date, time and phone number of the miss call after you choose it. But only can call this number.
- 4.4.5 Bluetooth
 - Set the Bluetooth status, turn on/off.
- 4.4.6 BT dialer
 - Can paired devices with smart watch.
- 4.4.7 Remote Notification
 - When there is SMS, incoming message from QQ and applications on the connected phone, the watch phone will alert you to read them.
- 4.4.8 Remote cameras
 - Use phone camera take photos, but remote by watch. Its need switch on the camera of phone in advance.
- 4.4.9 Anti lost
 - Watch seek phone, or phone seek watch.
- 4.4.10 Setting
 - Notice: In the security Settings, the safe code is 1122.
- 4.4.11 Pedometer
 - It can be adopted as a tool to avoid insufficient or excessive exercise by measuring calories or calories consumption based on collected data, such as number of steps, distance, time, etc., to control exercise.
 - If you want return to mail menu but keep pedometer during the exercise, please press the power button.
- 4.4.12 Sleep monitor
 - Show your sleep quality base on your sleep times.

- problem still unsolved, please contact our dealer or serviceman appointed.
- 6.1 Unable to switch on
 - The time of press the power button too short, please keep it more than 3 seconds.
 - Low power, please charge it.
- 6.2 Shut down automatically
 - Low power, please charge the watch.
- 6.3 Using time too short
 - Battery is not full, please make sure it is full power (full charge need2 hours at least).
 - During the use of SIM card, the power will be run off soon if the signal too poor.
- 6.4 Unable to charge
 - The battery's life will be reduced after few years, please check the battery can normal work.
 - Change a new charger if it is unworkable.
 - Please check the USB slot connecting good, if not, please try again.
- 6.5 No caller' name when incoming call
 - Forgot to choose upload the phone book when connected with BT, or un-selected keep upload the phone book.
 - Forgot to sync the phone book when reconnected, please pair the device and connect BT again.
- 6.6 Bad phone call voice
 - Watch and phone are separated too far, please close to each other, Bad signal of BT.
 - Bad signal of your own phone call, please change a better place for phone call.

7

SMS	Bluetooth call
	Local SMS
	Through the android synchronous push messages
Recreation	BT Music
Call reminder	Ring tone and Vibration
Dial	Embedded in the two dial
Two-way anti lost	Anti lost, Find each other, Compatible with Android
Pedometer	Step motion meter、Calorie Counter、mileage record
Sedentary remind	Sedentary remind
Sleep monitor	Sleep quality monitoring
Camera	Traditional photograph, Independently by the watch
	Remote camera, Watch controls the Android phones taking a picture
Others	Alarm, Calendar, Stopwatch, Calculator ; Compatible with Android ; QQ, WeChat, Facebook, Twitter and other real-time information can push to the watch
Remote Notification With Bluetooth	QQ, WeChat, Twitter, Facebook Such as instant messaging,
	Push SMS
	Pushing the news, System setting, some Apps

2

- application.
- Telephone service is including SMS, incoming and seek watch.
- Notice:
 - Please don't shut the Bluetooth notify service when you are clearing software by background or close background application software, It will affect the Sync function between watch and phone if shut it.
- 3.3Bluetooth Connection and Sync function
 - 3.3.1 From phone to watch
 - Phone setting -- turn on the Bluetooth --search for devices, please click pair devices when found Z50 , and also choose "yes" in your mobile phone, paired done.
 - Please choose "sure" when there is phone book request, meanwhile you'd better choose "no remind again", this is convenience when you connect next time (without remind again).
 - Notice: The Sync software can open in sync APP already installed and Accessibility, the mobile will show Bluetooth connected done after 2--5min; the watch will inform you the time of Sync with phone, than the Sync switched on. The message will sync to you watch when it incoming to mobile.
 - 3.3.2 From watch to phone
 - BT Dialer on Z50 -- search new device -- fond your smart watch (such as s9500) --connect, the processes of next are same with 3.3.1.
- 4. Base function:
 - 4.4.1 Message
 - Sync phone or watch message.
 - 4.4.2 Phonebook
 - 4.4.3 Dialer

4

- 4.4.13 Sedentary remind
 - You can set a time to remind you up to do some exercise, we suggest you this time could be one hours.
- 4.4.14 Quick response
 - It can download sync software when scan the quick response, if there is a new version need to update, please contact with our service, our company will provide a new link for your download.
- 4.4.15 Camera
- 4.4.16 File manager
- 4.4.17 Alarm
- 4.4.18 Calendar
- 4.4.19 Profiles
- 4.4.20 Audio player
 - Can play music from local or smart phone when connects to Bluetooth.
- 4.4.21 Camera
- 4.4.22 Image viewer
- 5. Notice:
 - 5.1 Full charge before use, the charge time needs 1--2 hours.
 - 5.2 Use the accessories cable and charger, or your android phone accessories.
 - 5.3 Bluetooth will disconnect when exceeds the distance, after switch on the Anti lost, the smart search function can't be use before reconnect with Bluetooth.
 - 5.4 Please reconnect with BT if it's disconnected occasionally (please Manual connect if the Bluetooth distance over 5 minutes). Please agree the phone book Sync otherwise there is no called phone book.
 - 5.5 When playing the music, some of music's name can show and some can't, it is normal. Because the android phone have difference sets.
- 6.Common trouble shooting:
 - Please refer below key function for any problems with the watch, if the

6