

SMART WATCH



User Manual

Please read this User Manual before using.

Compatibility with smart phones: Android 4.2 or newer versions; IOS 8.0 or newer versions.

1. Safety

1.1 Under the Company reserves the right to make any knowledge of the contents of this manual to make the right change without notice.

1.2 Please charge more than two hours before use.

2. Product Overview

2.1 Product Overview



POWER KEY: Power On/Off, wake up screen, turn off screen, back to home page.

USB Port: Charging, data transmission

Touchscreen: Capacitive touchscreen, all functions can be operated on touchscreen. sss

2.2 Quick enter and use

Quick tap and slide towards left to go to main page; Quick tap and slide towards right to go to previous page; press power key to go back to home screen.

2.3 Digital clocks



Power on→Setting→Clock→tap and select

2.4 Theme



Single one icon Four icons six icons

How to change the theme:

Enter menu→choose the UI and enter it to make settings

2.5 Gesture

Settings: Menu → Settings → Gesture

User can turn on/off below gesture functions.

2.5.1 Turn off the incoming phone call ringing. When there is an incoming phone call and the smart watch is ringing, quickly rotate your hand by 90°, ringing will stop.

2.5.2 Turn off the Alarm clock ringing. When Alarm clock is ringing, quickly rotate your hand by 90°, ringing will stop

2.5.3 Wake up the screen. When the screen light is off, raise your hand and screen light will on.

2.5.4 Rotate to left/right to shift pages of main menu.

2.5.5 Swing your hand(which wearing the watch) and start to answer an incoming phone call.

4.8 Notice

To read and check all the sync PUSH messages.

4.9 Remote Capture

Will remote control smart phone's camera to take photos. The photos will be storage in the smart phone.

4.10 Setting

Set Bluetooth, Time/Date, Volume, Display, etc.

4.11 Theme

Select different themes.

4.12 Pedometer

Can set Heart Rate Monitor at Pedometer. The Pedometer and Heart Rate Monitor Press Power Key to go back to home screen and keep the Pedometer working.

In the pedometer option where you can set the height and weight and exercise goals, on pedometer main screen you can see the number of steps, distance and calories and other sports information;

During exercise, if you wish to return to the main menu, without stopping the pedometer, press the power button, pedometer function will continue to run in the background. When the watch and a phone have been paired, pedometer information through the "Fundo" will sync to the phone & will display sports information.

Note: Must run the "Fundo" To achieve pedometer data synchronizing.

4.13 Sleep Monitor

Monitor the wearer's sleep quality.

4.14 Sedentary Reminder

Tap and turn it on, and set the reminding time and reminding method. The Prolonged Sitting Remind can remind you to stand up and take some walking after prolonged sitting, in order to keep a healthy daily living for people who are sitting too much time continuously.

Can set the remind period.

4.15 QR Code

Android smart phone scan the QR code to download the BT Notification apk.

Note: The QR code is for Android smart phone only. IOS smart device can download the APP from APP Store.

Search mediatek smartdevice or Fundo at APP Store to find it.

4.16 Alarm Clock

4.17 Calendar

4.18 Stopwatch

4.19 File management

4.20 Calculator

4.21 BT Music

When Bluetooth is pairing, the smart watch can play the music which is storage in the smart phone.

4.22 Audio recorder

5. Cautions

5.1 Charging before using. Charging time 1~2 hours. Activation of lithium ion batteries, charging for the first time suggested that for the first time the charging connection charge enough 10 to 12 hours

5.2 Can use smart phone's USB cable for charging.

5.3 The Bluetooth pairing could be disconnect when the distance is beyond 10 meters. Anti-lost function will be disconnected and need to connect it again.

5.4 If the Bluetooth is disconnected automatically, please pair it again.

6. Common Troubleshooting

When using, please refer to below instructions to handle trouble. If the trouble can't be solved referring to below instructions, please contact local seller for assistance.

6.1 Can't Power On

a) The press time may be too short, please long press the Power Key for 3 seconds.

b) The battery may be run out of power, please charge it.

6.2 Power Off automatically

Too low battery power, please charge it.

6.3 Stand by time too short

Not full charged before using. Make sure to charge the battery for 2 hours at least.

6.4 Can't charging

a) check the battery if it is still workable.

b) try another power adapter for charging.

c) Check if the USB cable is connecting in USB port properly.

6.5 The Contact's name doesn't display when there is incoming phone call
Phonebook doesn't sync to the smart watch. Please disconnect the devices and connect it again, don't forget to confirm the access of Phonebook sync connections when Bluetooth pairing.

3. Product use

3.1 Download the BT Notification (mediatek smartdevice / Fundo)



Use a Android smart phone to scan the QR code which is build-in the smart watch, and download the APK in your smart watch. The BT Notification doesn't need GPRS to support, it won't consume any GPRS data.

Notice: Mediatek SmartDevice compatible with Android 4.2 or newer version & IOS 8.0 or newer version.

Fundo compatible with Android 4.4 or newer version & IOS 8.0 or newer version.

3.2 Install and use the BT Notification (mediatek smartdevice / Fundo)

3.2.1. for Android smart phones

Use a Android smart phone to scan the QR code which is build-in the smart watch, and download the APK in your smartwatch. How to use and make setting of the BT Notification (mediatek smartdevice)

(In the Android smart phone) Tap and run the BT Notification→Accessibility settings→ tap and turn on the Mediatek SmartDevice or Fundo.



Tap BTNotificaiton to enable it.

Choose the Applications which you want to be BTNotificaitons at Notificaiton app.

Phone services including SMS service and Call service

Notice: Don't turn off the BTNotificaiton, or else some of the BT sync connections will be disconnect.

6.6 Poor voice quality of phone calling

a) The smart phone and the smart watch may be apart too far, please take them closer.

b) Due to poor mobile network signal.s

Warranty Card			
Information			
Model		Seller	
Name		Tel	
		Date	
Address			
maintenance record			
date	description	repair	remark