


# User Manual

**Please refer to this manual before  
using the product**

**V0.2**



1.4 This Android watch supports 3G WCDMA with NANO SIM card, and also compatible with 2G GSM.

1.5 To ensure the longer battery life, you are recommended to close high power consumption functions if they are needless for you such as Wake-up gesture, GPS, WiFi, BT or other specific functions.


It is normal that the watch temperature may increase mildly while it is connecting to internet with WIFI or 3G network because of higher power consumption.

**2**

## 1. Notes

1.1 The company reserves the right to modify the contents of this manual without any further notification. It is normal that some functions may vary in certain versions of software. The software can be upgraded online.

1.2 Please charge this product with the configured charger for no less than 2 hours before using it.





1.3 Please power off when insert SIM card by opening the card cover (Corresponding screws and screw drivers are included in the package), please remember to use the waterproof ring surrounding the SIM cover, and tighten the screw when finish inserting SIM card to avoid water inflow.

**1**

## 2. Product Overview

2.1、 basic introduction



**3**

## 2.2、 Basic Operating

1. Long press the button to turn on the watch, it will be slower for app optimizing for the first time to enter into the Android OS:

I ) language settings.

II ) Personal information settings.

III ) Scan the QR code to download and install the software with your smart phone for BT connecting and information synchronization.

2. While the watch is working, you will enter the selection page by long pressing the button for around 2 seconds:

I) Power off

II) Reboot

III) Power save (The watch will enter into the power save mode automatically when the battery is very low)

IV) Recent Task

V ) full/small (Shift the round/square UI of self-installed APKs)

### 3. Menu Operating

1 ) Slide the watch face to the left to enter the main function menu

2 ) Slide the watch face to the right to enter the notification menu

4

3 ) Slide the watch face to the bottom to enter the status bars and short-cut settings

I ) First page: telephone signal status, BT connecting status, time and date

II ) Second page: Vibrator switch, Wake-up gesture switch, :Brightness, flight mode, BT switch, WIFI switch, GPS switch etc.

III ) Third page: pedometer

4 ) Slide the watch face to the top to view the weather information (network is requested)

5 ) Slide the menu to the left to return to the previous menu

## 2.4 Settings of watch faces



5

Long press the watch face for around 1 second to enter the watch faces selection pages, slide the watch faces to select the preferable one and click it .

Download new watch face in server (this feature requires using network):

In the watch face interface, long press it and switch to other watchface function, and then slide to the left, click the blue +, you can enter the download interface, sliding up and down to choose the favorite one to download, click the blue down instructions button to start downloading, press the power button to return to the watchface interface.

Delete the new downloaded watchface from the server:

In the watchface interface, long press it and switch to other watchface features, and then find the downloaded watchface, click the upper left corner of blue - to delete (only downloaded one can be removed, original one can not be deleted)

6

## 3.Detailed use instructions

### 3.1 Download synchronized software

Scan QR code with your smart phone to download and install the synchronized software.  
(Settings—Mobile Assistant)

Note :

1.This program is only used for synchronization between watch and cellphone.

2.You are recommended to download the software when WIFI is workable.

3.If you have downloaded relevant software from other channels, please check the software version, and use the latest version of synchronized software to ensure the normal use of its functions. Please update the synchronized software in time.

### 3.2 BT and synchronization

Switch on the BT of your phone and the watch.

7



- 1.Open WiiWear
- 2.Click "Scanning device"
- 3.Search the surrounding BT devices
- 4.Find KW88 and finish the BT connecting.

Settings: information synchronization, remote camera, music remote control, anti-lost etc.

3.3 Functions introduction

Dialer : SIM card is needed for making a call.

Contacts : Add new contacts or sync the contacts of cellphone

Messaging : SIM card is needed for messages.

Setting : Basic settings of the watch, such as BT, clock, volume, reset and etc..

- 1.Sound
- 2.Display
- 3.App List Style
- 4.Connect: BT, WIFI, GPS settings
- 5.Phone Assistant : QR code for WiiWear
- 6.Gesture : screen on raising, pedometer service
- 7.Power saving
- 8.Language & input
- 9.Date & time
- 10.Reset equipment

**8**

Gallery: Check the pictures taken by the camera.

Camera: take pictures or video recorder

Fine me:

You can find your phone via your watch when the BT is being connected.

Your phone will have an alert while the function is using, make sure the BT is being connected.

Weather: Local weather information (network is needed )

#### **4. Precautions for use**

- 4.1 Please charge the smart watch completely before use. Charging time is 1-2 hours.
- 4.2 Please use phone charger adaptor or computer USB port to connect our standard magnetic cable to charge the watch, Please make sure that the cable connecting is good during charging.
- 4.3 Anti lost function is standby only while the BT is being well connected.

#### **5. Common trouble shooting ways**

In case there' s a problem during the using of

**10**

- 11.Uninstall application
- 12.About watch: product information and OTA

Clock : Create and edit the alarm clock. Maximum 8 alarm clocks can be set.

Sound recorder: Record the sound

Calendar: Month, date and week can be displayed.

File : Manage the files in the memory of watch.

Browser

Remote control: Remote control the music of the cellphone

Remote Capture : Remote control the camera of the cellphone

Music: Play the music in the memory of watch

Health : Pedometer, heart rate checking

**9**

your watch, please solve it accordingly by the following ways. If the problem still exists, please contact your seller or designated maintenance personnel.

#### **5.1 Cannot turn on the watch**

- 1)Long press the button
- 2)It is possible the battery is used up. Please recharge and start again.

#### **5.2 The watch turn itself off**

It is possible the battery is used up. Please recharge and start again.

#### **5.3 Short battery life**

- 1.Not full charging battery, please make sure the enough time for charging your battery.( No less than 2 hours).
- 2.Turn off the needless functions which are high power consumption such as GPS, WIFI, , walk-up gesture etc.

#### **5.4 Cannot be charged**

- 1.Check whether the battery can be used. The

**11**

performance of battery will be reduced after several years using.

2.Check whether the charger is workable, change another one.

3.Check whether all the connecting is good, try again.

Warranty Card			
Customer Data			
Model No.:		Seller	(signature)
Customer name		Contact number	
Sales Tel		Purchase Date	
Product IMEI code			
Client add.			
Sales add.			
Abstract			
Date	Problem	Repair	Remarks