

•Read indications carefully

- please read details before using the smart band for avoiding unnecessary bothers.
- this indication is based on initial settings of the smart band.
- if those images are out line with real objects, we sincerely beg your understanding.
- please save the indications for subsequent repair.

•appearance explanations



•Accessories

- Principal machine *1
- Waist band *1
- Charge wire *1
- User guide *1

•Function explanations

- working voltage: 3.0

- time counting:0-9999
- distance presence:0-99.9km(the metric system)
- calorie consumption:0-9999
- permanent presence:in 24-hour time system
- Heart Rate Monitor
- photograph
- sleeping quality checking
- a reminder of long-time sitting
- caller identification
- data memorizing for seven days
- ultra-low power consumption and shutdown in 5s automatically
- Bluetooth
- Clock
- preventing losing system

•Operations

【click the button: light up screen, change modes】
时间模式 (TIME MODE)

12-23
17:30

【knock at smart band four times continually:enter into or exit heart rate monitor】
心率监测 (heart rate monitor)
Please keep quite which benefits heart rate monitor. Once you enter into the mode, the band will start this function.



计步模式 (step mode)



距离模式 (distance mode)




卡路里模式 (calories mode)



【knock at smart band four times continually:enter into or exit sleep mode】

睡眠监测模式 (sleep monitor mode)

Attention: It will continue heart rate monitor and store the relevant data in sleep mode.




Client explanations:


•Charge the smart band before first use, then scan the below two-dimension code and download mobile APP. Present android mobile can show how to use gitfit software, and IPHONE is the same as android.



•make sure that Bluetooth is open, start the software, enter into main interface.



•click device's items, bind and add to new device.



LINK OK will show up on device in 3 seconds once it connect successfully, then it will exit with updating new data automatically into mobile APP, so please wait patiently.

LINK OK


•Get the homepage and click the mark of heart rate, then get into heart rate monitor,you can open or close this function.



•Get photograph function through the device of mobile APP

Once you enter into photograph mode and click the button, you can take photos. If you want timing photo, the photograph function is a better choice for you.

•Choose the device through mobile APP to start call reminder, long-time sitting reminder and alarm clock.



When the band satisfies scheduled conditions and then vibrates, a notice will emerge, next, press the exiting instruction with a long time.



•Get the function of preventing losing through the device of mobile



When the band vibrates and a reminder notice emerge, press the exiting instruction with a long time.At this time it is beyond using distance for smart band and mobile..



Warm prompt

Necessary conditions for hardware of mobile:



iOS 7.1and higher edition Android 4.3and higher edition allowing Buletooth4.0

Too clingy or loose is not good for heart rate monitor, therefor, wear smart band in a right way does well in error reducing.Here is an example image below.



Smart band will clear itself in every morning and record new data. Besides, it can memorize 7 days' data, and if you connect your mobile, the data will update automatically.Can't connect the device in Bluetooth:some mobiles will be abnormal when reboot;please reboot the Bluetooth or reboot smart phone for pairing device.