L9 Smart Watch User Manual

Please refer to user manual before use V1.0

Thanks for choosing our L9 smart watch. Please read this user manual to fully understand how to use this device concisely. Our company reserves the right to amend the user manual without prior or further notice.

Notice: Make sure that you turn on the Bluetooth on your smart phone at the same time, so Bluetooth device around can be found, iphone user need to open Bluetooth on "settings" page, otherwise, smart watch cannot be found.

When smart watch asks "synchronize date and time?" click "Yes" to synchronize time. Smart watch can also receive synchronized information from smart phone.

3.4 Function menu introduction

- contacts : synchronize contacts on the smart phone.
- Dial : Bluetooth dial. After successful Bluetooth connect, smart watch can dial phone number directly:

Dial from call logs: Transfer interface from dial page to call logs page, and choose one call record to call back directly.

Pick up incoming calls: When smart phone gets a call, smart watch also has call reminding via ring, name and phone number will display on the screen.(smart phone have already open incoming call display function). You can choose to pick up or hang up according to prompts given on the screen. If need digital dial plate via communication, slide left on the screen, then it will come out

- Message : Synchronize message from smart phone (IOS smart phone check on the remote notification);
- Remote notification [1]: display synchronized information from smart phone, such as QQ, WeChat, message, time, Twitter, Facebook etc.,
- Bluetooth dialer 🖈 : search Bluetooth device around, pair and connect. If many Bluetooth devices are around, then suggest you to search smart phone via Bluetooth dialer, because smart phone has only one name and is easier to identify Long press connected Bluetooth device to delete pair operation between connected
- Pedometer (1): Pedometer activates by default while power on to record your sports data. Scroll up on pedometer interface access to setup page. You can set up individual information including gender, height, weight etc., and check historic sports record.
- Music player =: After successful Bluetooth connect, music on smart phone can be played on the smart watch synchronously.

• Tool

Calendar : display month, date, week

Alarm (3: add alarm to set up ring, vibration, cycle period and times. Anti-lost : find your smart phone via watch (with successful Bluetooth connect)

1. Prepare before use

- 1.1 Check device model and accessories.
- 1.2 Charge the battery for 2 hours above

2. Brief introduction

2.1 Basic structure



Call logs \(\subseteq \): check your recent calls and call back or edit before call.

Calculator ##: use addition subtraction multiplication to calculate.

Find a phone ocitic to find your phone, alarms are raised from smart phone. Camera (remote camera) : use smart watch to control smart phone camera and take

Notice: Photos are always saved on the smart phone, use smart phone to check photos, some smart phone cannot see photos via picture browser, you can check the corresponding files. Remote camera needs to open camera function and stay on this page on the smart phone first. Then smart watch can take photos synchronously.

• Health management: 🌉

Sedentary 👢 : set up reminding time to stand up and move. Suggest you to make some movements every hour. Default setting is once in half an hour. Sleep monitor (: sleep testing time by default is from 10:00 pm to 8:00 am next

• Settings : set up basic functions on smart watch, such as Bluetooth, clock, volume, restore factory settings and check basic information on the device.

- 4.1 Fully charge before use, at least 1-2 hours for charging. Make sure that charging ports are well contacted.
- 4.2 Use standard qualified charging cable.
- 4.3 If Bluetooth gets disconnected due to distance, "find a phone" function needs to be activated after successful Bluetooth connect once again.
- 4.4 Bluetooth may get disconnected sometimes, please reconnect again.
- (If over 5 minutes no connect, then need to reconnect manually). Please choose agree to synchronize phone list while connecting. Otherwise, it will not display phone list name or make other remote operation.
- 4.5 Music function, some android smart phone may not display song names due to different models.

6. Troubleshooting

If there is any problem while using the device, please refer to below methods. If the problem is still unsolved, please contact retailer or designated maintenance person.

6.1 Unable to power on

Press time is too short, please press on power button over 3 seconds

2.2 Brief operation guide

Power on L9 smart watch. Slide on the touch screen access to function menu. On function menu interface, swipe left to enter next page. Swipe right to return previous page, or click shortcut key to choose different function page.

Notice: If smart watch will not power on/off normally, please long press "Power button" for 8 seconds for a forced shutdown and restart again.

2.3 Dial plate

Dial plate image and setup method: 3 stylish clocks for your free change.







Tip 1: Power on smart watch. On the dial plate page, long press on the screen access to clock interface. Swipe left or right to change clock style and confirm by a click. Tip 2: Click "Menu-settings-clock-clock type" to choose your preferred clock style. Click to confirm.

2.4 Main interface display



3. Device operation tips.

3.1 APP download

Scan "OR code" on the smart watch to download app.

3.2 Bluetooth connect and synchronization

3.3 Connection between smart phone and smart watch (realize communication function)

Turn on "Bluetooth" on smart watch, Click "search device" and find your phone(such as: Iphone) Choose "pair" and confirm to synchronize phone list. After successful connect, then realize communication function.

Low battery, please charge the battery.

6.2 Smart watch power off automatically

Low battery, please charge the battery.

6.3 The use of the smart watch is too short

Battery is not fully charged (please fully charged over 2 hours).

6.4 Unable to charge properly

Check if charger is damaged and change a new charger.

Check if charging ports have a good connection.

6.5 Incoming calls without name display

Bluetooth disconnected so phone list are not synchronized.

Or haven't chosen upload phone list. If Bluetooth disconnected, please pair and connect again.

6.6 Poor voice quality

It's too far between smart phone and watch. Or Bluetooth signal is too weak, please

Cell phone signal is not strong in your current position. Please change your position to try again.