


User Manual for Smart Watch



Contents

I. Quick Guide

- 1.1 Power button Function
- 1.2 Charging
- 1.3 Touch Screen Guide
- 1.4 Status Interface Introduction
- 1.5 Bluetooth Connection
 - 1.5.1 FunDo Download & Install
 - 1.5.2 Phone Paring

II. Function Introduction

- 2.1 Clock Face Switching
- 2.2 Dialer
- 2.3 Bluetooth
- 2.4 Find my device
- 2.5 Phonebook

- 2.6 Call logs
- 2.7 Remote Notifier
- 2.9 File Manager
- 2.10 Sedentary Reminder
- 2.11 APP download
- 2.12 Audio Player
- 2.13 Settings
 - 2.13.1 Setting local city & clock
 - 2.13.2 Sound
 - 2.13.3 Volume
 - 2.13.4 Display
 - 2.13.5 Languages
 - 2.13.6 Motion
 - 2.13.7 Reset equipment
 - 2.13.8 About

- 2.14 Sound Recorder
- 2.15 Alarm
- 2.16 Calendar
- 2.17 Caculator
- 2.18 World Clock

III. Function Introduction

- 3.1 Step Count
- 3.2 Sleep Monitor
- 3.3 Heart-Rate Monitor
- 3.4 Barometric Pressure
- 3.5 Stopwatch
- 3.6 Compass
- 3.7 Sports Mode + Track Sync
 - 3.7.1 Sports Mode
 - 3.7.2 Sports History & Track Syncc

IV. Precautions for Use

V. Common Fault Resolution

- Charging under power-off status, the battery icon will stop blinking after fully charged. Turn on the smart watch is available during charging.

I.Quick Guide

1.1 Power button Function:

- a. Press power button continuously to turn the device on.
- b. Press power button continuously to turn the device off.
- c. Press power button shortly to lock the screen.
- d. Under sub-menu, press power button shortly to back to clock interface.
- e. Under crashed status, press power button continuously more than 10 seconds to reboot the device.

1.2 Charging


- Connect Magnetic USB Cable charging port with standard adaptor or PC, and match magnetic port with the smart watch bottom, make sure successfully connected.
- After connected, down slide the clock interface, the battery icon on upper right will be blinking under charging status. After charging completed, the battery icon stops blinking and reminds 'Charging Completed', and then battery icon with full rungs.
- After charging completed, cut off the connection between Magnetic USB Cable charging port and adaptor or PC prior, and then cut off the connection between the magnetic port and smart watch bottom.

1.4 Status Interface Introduction

Icon	Function Description	Icon	Function Description
	Battery Volume, More rungs, More powerful.		Alert Type
	Bluetooth button, Grey for turn-off, Blue for turn-on		Bluetooth status, dark for pairing completed, light for pairing failed.
	Click to view the FunDo APP QR Code		Switch screen brightness level.

1.5 Bluetooth Connection

1.5 FunDo APP Download & Install

- a. Down slide the clock interface as picture  enter status interface, click the upper right QR code icon, enter FunDo APP QR code download interface, scan the QR code to enter download & install guide.
- b. Left slide the clock interface, enter sports mode menu interface and click the main menu icon, down slide to find the 'APP download' on the main menu interface, click it to enter FunDo APP QR code download interface, scan the QR code to enter download & install guide.
- c. Search on APP Store to download & install.


1.3 Touch Screen Guide

- a. Up slide the clock interface, enter to the main function interface(following: Steps Today/Sleep Data/Heart-Rate Monitor/Barometric Pressure Monitor/ Height Monitor/Stopwatch/Compass/Status Interface) on forward circulation.
- b. Down slide the clock interface, enter to the status interface (Bluetooth status / Battery status / Alert Type / APP QR code / Screen Brightness / Bluetooth), and then down slide, enter the main function interface(following: Compass / Stopwatch / Height Monitor / Barometric Pressure Monitor / Heart-Rate Monitor / Sleep Data / Steps Today) on backward circulation.
- c. Left slide the clock interface, enter to the sports mode menu interface (Walking/Cycling/Outdoor Run/Indoor Run/Football/Crosscountry/-Climbing/History/Sports Setting).
- e. Right slide the clock interface, enter to Bluetooth connection interface, notifications will be pushing on smart watch after connection completed.

1.5.2 Phone Paring

Need to connect twice between the smart watch and phone. Turn on the Bluetooth on the smart watch & phone both in priority.

- a. Connection on APP:Open App, click 'more' on down right, click 'Add', click 'find'on upper right, start to search available Bluetooth Device nearby, click the Bluetooth Device name to pair, APP will turn back to 'More'interface automatically after pairing completed, and display the smart watch name on connection status row.(Notice:Paring on IOS system, after APP turned back to 'More'interface, 2s later the 'Bluetooth paring request' will pop up as picture,only after click 'paring', all the functions on APP could be fully supported. Paring on Android system, please ignore this notice).



- b. Connection on Phone:Enter 'Settings'- 'Bluetooth', start to search available Bluetooth Device nearby automatically on the phone, click the Bluetooth name to pair; Or, enter main menu interface on the smart watch, start to search available Bluetooth Device nearby automatically, click the Bluetooth name to pair.

II.Function Introduction

2.1 Clock Face Switching

Under Clock interface, simple click the screen once each time to switch the clock face.

2.2 Dialer

After Bluetooth connected, click 'Dialer' on Main menu interface, input the numbers and click Dial icon for calling.

2.3 Bluetooth

Click 'Bluetooth' on main menu interface for setting: to turn on/off Bluetooth; to be visible or not.

Bluetooth connection: Click 'BT connectivity', click 'search new device' to find available Bluetooth Devices nearby, click the Bluetooth device name to pair.

2.4 Find my device

After Bluetooth connected, click 'Find my device', click the icon as picture, the icon would keep on blinking, and then the phone would be vibrating & ringing. Click the icon again, the icon would stop blinking, and then the phone would stop vibrating & ringing.



2.9 File Manager

Click 'File manager' on main menu interface, check the files and contents on the smart watch.

2.10 Sedentary Reminder

Click 'Sedentary Reminder' on main menu interface, to turn on/off the reminder, to set the time interval between 0-300 minutes (not working on sleep monitor time).

2.11 APP Download

Click 'APP Download' on the main menu interface, enter FunDo APP QR code download interface, scan the QR code to enter download & install guide.

2.12 Audio Player

After Bluetooth connected, click 'Audio Player' on main menu interface to enter audio player control interface.

2.13.6 Motion

Click 'Settings' on main menu interface, click 'Motion', to turn/on the wake-up gesture. Wake-up gesture would be workable on turn-on status only.

2.13.7 Reset Equipment

Click 'Settings' on main menu interface, click 'Reset' to reset the equipment or not.

2.13.8 About

Click 'Settings' on main menu interface, click 'About', to check the device name, device address, connected status and current software version.

2.14 Sound Recorder

Click 'Sound Recorder' on main menu interface, to control record, save record, and adjust the volume level when you play the record.

2.15 Alarm

Click 'Alarm' on main menu interface, to set the alarm time, tone, alert type and repeat times(Set 5 Alarms in maximum).

2.5 Phonebook

After Bluetooth connected, click 'Sync' to sync the contacts from the phone to the smart watch(only 100 contacts could be saved).

2.6 Call logs


After Bluetooth connected, click 'Call logs' on main menu interface, to check the call logs.

2.7 Remote Notifier

After Bluetooth connected:

- Click 'Remote Notifier' on main menu interface, to check the notifications.
- Right slide the clock interface, to check the notifications.

2.8 Remote Capture

After Bluetooth connected, turn on the Camera button on APP first, click main menu 'Remote Capture' on smart watch, watch interface changes to be the icon as picture , while the phone camera will be turned on. Click the icon, to remote capture the phone camera, the photo would be saved on the phone.

2.13 Settings

2.13.1 Setting local city & clock

Click 'Settings' on main menu interface, click 'city' to select the city, click 'clock' to set the time or sync time. Turn on the 'Time Sync' to sync the time & date after connected with the APP, turn off the 'Time Sync' to set the time & date.

2.13.2 Sound

Click 'Settings' on main menu interface, click 'sound', to set the alert type, Ringtone, notification tone.

2.13.3 Volume

Click 'Settings' on main menu interface, click 'volume', to set Multimedia, Ring, Notification volume level.

2.13.4 Display

Click 'Settings' on main menu interface, click 'Display', to set the brightness and Screen time out.

2.13.5 Languages

Click 'Settings' on main menu interface, click 'Language', to set the language.

2.16 Calendar

Click 'Calendar' on main menu interface, to check the date, click the calendar icon to check the calendar details.

2.17 Calculator

Click 'Calculator' on main menu interface, input numbers for calculating.

2.18 World Clock

Click 'World Clock' on main menu interface, to check the default timezone, click the upper arrow icon to check different timezone.

III. Common Function Introduction

3.1 Step Count

Up Slide the clock interface, to check the Step Count, Mileage, the Percentage between Current Step & Goal Step, step count for this week & history, to set the goal step. After connected with APP, the data for step count, mileage and calories on smart watch could be synced to APP.

3.2 Sleep Monitor

Default sleep time 21:00-09:00, the smart watch will enter to sleep monitor status automatically during that time. Would record today sleep data and history sleep record for this week. After Bluetooth connected, the sleep data could be synced to APP.

3.3 Heart-Rate Monitor

After wearing on hand, enter to Heart-Rate monitor interface, click heart-rate icon to test, click 'entry history' to check the history data. After Bluetooth connected, the heart-Rate data could be synced to APP.

3.4 Barometric Pressure

- Enter Barometric Pressure interface, to check current barometric pressure data.
- Click height data to reset, after reset the data, would start to record the relative height data.


3.5 Stopwatch

Enter Stopwatch interface to use, 20 sets of data could be saved in maximum, click the upper icon to check the saved data.

- **Sport Setting:** To set the Metric/Metric Imperial, Per Mile Reminder, Pace Reminder, Cost Time Reminder, Goal Mileage, Daily Sport Reminder, and personal data. Those reminders would be workable after setting.

3.7.2 Sports Track Sync

After Bluetooth connected, the sports history data could be synced to APP. The sports track and data could be checked on APP as below:



IV. Precaution for Use

1. Fully charge the battery before using, suggested charging time more than 2 hours.

3. Smart watch usage time too short

The battery may not be fully charged, please ensure enough charging time(charging time for 2 hours at least)

4. Smart watch could not be charged

- Please check if the battery is workable or not, after several years using, the battery would get performance degradation.
- Please check if the Magnetic USB Cable or adaptor is workable or not, try to use another Magnetic USB Cable or adaptor.
- Please check if successfully connected the FPC contactor between the USB cable & smart watch, try more times to reconnect.

5. No caller name shown on incoming call

- After Bluetooth connected, may reject to Sync Contacts, or, not select Sync Contacts always.
- After Bluetooth disconnected and then reconnected, may failed sync contacts, please re-pair on the phone again.

6. Call quality not good

The distance between the smart watch & phone may be too far, please keep them within the effective connection distance.

3.6 Compass

Enter Compass interface, rotate the smart watch in clockwise direction and then in counterclockwise direction for 1st using, then enter compass interface, to check the correct direction.

3.7 Sports Mode & Track Sync

3.7.1 Sports Mode

• Sports Mode includes Walking, Cycling, Outdoor Run, Indoor Run, Climbing, Football, Crosscountry. Choose to open GPS Service or not under Walking Mode, Outdoor Run Mode, Climbing Mode, Crosscountry Mode. The sports track would be saved when GPS Service opened only, if not opened, no track would be saved. The sports data would be saved under Sports Mode (stay sports mode more than 3 minutes, sports data would be saved automatically). **Notice:** The sports data would be saved after GPS Service successfully located, no data would be saved if GPS Service failed located.

- **Sport History:** The sports data under sports mode could be saved in history.

2. Please use original Magnetic USB Cable for charging

3. If exceeded the effective connection distance between the smart watch & phone, the Bluetooth would be disconnected. After disconnected, back to effective connection distance within 5 minutes, the Bluetooth would be reconnected automatically.

4. Audio display, according to different phone model compatibility, the song name may not be displayed on the phone, which is normal circumstance.

V. Common Fault Resolution

Any fault during using, please refer to below claims for resolution. If the fault still existed, please contact the distributor or specified maintenance crew to solve.

1. Smart watch could not be turned on.

- The continuous pressing time may be too short, please press the power button continuously more than 3 seconds.
- May be low battery, please charge the smart watch more than half an hour.

2. Smart watch shuts down automatically.

May be low battery, please charge the smart watch more than half an hour.